



USER'S MANUAL



THREE-PHASE HYBRID STORAGE INVERTERS

3PH HYD5000-HYD20000-ZSS



ZUCCHETTI
Centro Sistemi



IMPORTANT MESSAGE

Dear Customer,
inside the box of this product you can find the manuals in English.
Please note that revised and/or updated versions of the
aforementioned documentation may be available, therefore in
order to guarantee the correct installation procedure it is necessary
to check the documentation available on the website
www.zcsazzurro.com in the documentation or products section or
directly by scanning the QrCode placed on the front of the product.

Thank you
Team Azzurro Zcs

3PH HYD5000-HYD20000-ZSS hybrid inverter User Manual



Table of Contents

1. Introduction	10
2. Preliminary safety instructions	11
2.1. Safety Notes.....	11
2.2. Assembly and maintenance notes.....	11
2.3. Symbols on the inverter	13
3. Installation.....	15
3.1. Product overview.....	15
3.2. Package contents.....	17
3.3. Requirements for the installation environment	19
3.4. Installation tools.....	20
3.5. Wall installation position.....	22
3.6. Assembly instructions.....	23
4. Electrical connections.....	24
4.1. Connection of protective ground cables (PGND).....	27
4.2. Connecting to grid	29
4.3. Connecting to the load circuit.....	30
4.4. Photovoltaic connection.....	31
4.5. Connecting the battery	35
4.2.1. Installing Pylontech batteries	35
4.2.1.1. Connecting a single battery tower	35
4.2.1.2. Communication between the BMS and Battery Modules	38
4.2.1.3. BMS and Inverter communication	39
4.2.1.4. Power connections	43
4.2.1.5. Channel configuration (single Pylontech tower)	47
4.2.1.6. Installation with two battery towers (with SC500 and SC1000 BMS).....	50
4.2.1.7. Communication between the BMS (SC500 and SC1000) and Battery Modules.....	50
4.2.1.8. Power connections (SC500 and SC1000 BMS).....	54
4.2.1.9. Channel configuration of Pylontech dual tower (SC500 and SC1000)	55



4.2.1.10.	Installation with two battery towers (with Wi-Fi/USB SC500 and Wi-Fi/USB SC1000 BMS)	59
4.2.1.11.	Communication between BMS (Wi-Fi/USB SC500 and Wi-Fi/USB SC1000) and Battery Modules	59
4.2.1.12.	Power connections (Wi-Fi/USB SC500 and Wi-Fi/USB SC1000 BMS).....	63
4.2.1.13.	Channel configuration (two Pylontech towers - Wi-Fi/USB SC500 and Wi-Fi/USB SC1000))	64
4.2.2.	WeCo 5K3 battery installation.....	68
4.2.2.1.	Only one 5K3 battery tower connected	68
4.2.2.2.	Communication between HV BOX and 5K3 Battery Modules.....	70
4.2.2.3.	5K3 HV BOX and Inverter communication	72
4.2.2.4.	5K3 power connections	75
4.2.2.5.	Channel configuration (single WeCo 5K3 tower)	77
4.2.2.6.	Installation with two battery towers 5K3.....	80
4.2.2.7.	Communication between HV BOX and 5K3 Battery Modules.....	81
4.2.2.8.	5K3 HV BOX – Inverter communication	81
4.2.2.9.	Power connections with two 5K3 battery towers.....	85
4.2.2.10.	Channel configuration (dual WeCo 5K3 tower)	86
4.2.3.	WeCo 5K3XP battery installation.....	90
4.2.3.1.	Only one 5K3XP battery tower connected.....	90
4.2.3.2.	5K3XP HV BOX and 5K3XP Battery Modules communication.....	92
4.2.3.3.	5K3XP HV BOX and Inverter communication.....	94
4.2.3.4.	5K3XP power connections.....	97
4.2.3.5.	Channel configuration (single WeCo 5K3XP tower).....	99
4.2.3.6.	5K3XP battery tower start-up.....	102
4.2.3.7.	Installation with two 5K3XP battery towers	104
4.2.3.8.	Communication between HV BOX and 5K3XP Battery Modules	105
4.2.3.9.	5K3XP HV BOX – Inverter communication.....	105
4.2.3.10.	5K3XP power connections.....	109
4.2.3.11.	Channel configuration (dual 5K3XP WeCo tower).....	110
4.2.3.12.	Start-up of dual 5K3XP battery tower	114
4.2.4.	5K3 and 5K3XP WeCo mixed installation	116
4.2.4.1.	Start-up of mixed 5K3XP and 5K3 battery towers	117



4.2.5.	Installation of Azzurro HV battery.....	119
4.2.5.1.	Connecting a single battery tower	119
4.2.5.2.	Communication between the BDU and Battery Modules	122
4.2.5.3.	BDU Inverter communication	123
4.2.5.4.	Power connections	126
4.2.5.5.	Channel configuration (single Azzurro tower)	129
4.2.5.6.	Installation of dual battery tower.....	133
4.2.5.7.	Communication between the BDU and Battery Modules	134
4.2.5.8.	Communication between BDU 1 and BDU 2	135
4.2.5.9.	BDU2 Inverter communication.....	136
4.2.5.10.	Power connections	139
4.2.5.11.	Channel configuration (dual Azzurro tower)	143
4.2.2.	Installing Azzurro HV Smart 5K batteries.....	147
8.2.1.1.	Connecting a single battery tower	147
8.2.1.2.	Communication between BDU Smart 5K and Smart 5K Battery Modules.....	150
8.2.1.3.	BDU Smart 5K and Inverter communication	151
8.2.1.4.	Power connections	154
8.2.1.5.	Channel configuration (single Azzurro Smart 5K tower)	157
8.2.1.7.	Installation with two battery towers	161
8.2.1.8.	Communication between the BMS (SC500 and SC1000) and Battery Modules.....	162
8.2.1.9.	Comunicazione fra BDU Smart 5K 1 e BDU Smart 5K 2	163
8.2.1.10.	BDU Smart 5K and Inverter communication	164
8.2.1.11.	Power connections	167
8.2.1.12.	Channel configuration of Smart 5K dual tower	169
2.	External communication.....	173
2.1.	USB/Wi-Fi	173
2.2.	DRMs Interface - Logical Interface.....	174
2.3.	COM communication - Multifunction.....	177
2.4.	Measurement of currents exchanged with the grid.....	180
2.4.1.	Direct connection of CT sensors	180
2.4.2.	Connecting the Meter	183
2.4.3.	Measuring the photovoltaic production.....	187



2.4.3.1.	Configuring the Meter parameters.....	188
2.4.3.2.	Checking the correct installation of the Meter.....	191
2.5.	Inverter Mode in parallel.....	193
2.5.1.	Connections between inverters.....	193
3.	Buttons and indicator lights.....	195
4.	Operation.....	196
3.1.	Before configuration (follow carefully).....	196
3.2.	Commissioning.....	197
3.2.1.	OSD language options.....	198
3.2.2.	Setting of date and time, confirmation.....	198
3.2.3.	Importing of safety parameters.....	198
3.2.4.	Setting the input channels.....	200
3.2.5.	Setting battery parameters.....	201
3.3.	Main menu.....	202
3.3.1.	Basic settings.....	205
3.3.2.	Advanced settings.....	214
3.3.3.	Event list.....	219
3.3.4.	System interface information.....	219
3.3.5.	Energy statistics.....	222
3.3.6.	Software Update.....	224
5.	Technical data.....	226
5.1.	3PH HYD5000-HYD8000-ZSS technical data.....	226
5.2.	3PH HYD10000-HYD20000-ZSS technical data.....	227
6.	Troubleshooting.....	228
7.	Uninstalling.....	237
7.1.	Uninstallation steps.....	237
7.2.	Packaging.....	237
7.3.	Storage.....	237
7.4.	Disposal.....	237
8.	Monitoring systems.....	238
8.1.	External Wi-Fi adapter.....	238
8.1.1.	Installation.....	238



8.1.2.	Configuration	239
8.1.3.	Check	248
8.1.4.	Troubleshooting	249
8.2.	Ethernet adapter	254
8.2.1.	Installation	254
8.2.2.	Check	256
8.2.3.	Troubleshooting	257
8.3.	4G adapter	258
8.3.1.	Installation	258
8.3.2.	Check	260
8.4.	Datalogger	263
8.4.1.	Preliminary notes on how to configure the datalogger	263
8.4.2.	Electrical connections and configuration	265
8.4.3.	ZSM-DATALOG-04 AND ZSM-DATALOG-10 Devices	268
8.4.4.	WI-FI CONFIGURATION	268
8.4.5.	Ethernet configuration	269
8.4.6.	Checking that the datalogger has been configured correctly	275
8.4.7.	ZSM-RMS001/M200 and ZSM-RMS001/M1000 Devices	278
8.4.7.1.	Mechanical description and Datalogger interface	278
8.4.7.2.	Connecting the Datalogger to the inverters	279
8.4.7.3.	Internet connection via Ethernet cable	279
8.4.7.4.	Connecting the power supply and battery pack to the Datalogger	279
8.4.7.5.	Connecting the LM2-485 PRO cell irradiation and temperature sensor to the datalogger 279	
8.4.8.	Configuring the Datalogger	281
8.4.8.1.	Configuring the Datalogger on the ZCS Azzurro portal	283
8.4.8.2.	Network configuration	284
8.4.9.	Local monitoring	285
8.4.9.1.	Requirements for installation of local monitoring	285
8.4.9.2.	Features of local monitoring	285
9.	Warranty terms and conditions	287



General instructions

This manual contains important safety instructions that must be followed during installation and maintenance of the equipment.

Please keep these instructions!

This manual must be considered an integral part of the equipment, and must be available at all times to everyone who interacts with the equipment. The manual must always accompany the equipment, even when it is transferred to another user or plant.

Copyright statement

The copyright of this manual belongs to Zucchetti Centro Sistemi S.p.A. No part of this manual (including the software, etc.) may be copied, reproduced or distributed in any form or by any means without the permission of Zucchetti Centro Sistemi S.p.A. All rights reserved. ZCS reserves the right to final interpretation. This manual is subject to change based on feedback from users, installers or customers. Please check our website <http://www.zcsazzurro.com> for the latest version.

Technical support

ZCS offers full technical support and advice which can be accessed by making a direct request through the website www.zcsazzurro.com.

The toll-free number for Italy is: 800 72 74 64.

Preface

General information

Please read this manual carefully before installation, operation or maintenance.

This manual contains important safety instructions that must be followed during installation and maintenance of the system.

This manual describes the installation, electrical connections, maintenance and troubleshooting of the following inverters:

3PH HYD5000 ZSS / 3PH HYD6000 ZSS / 3PH HYD8000 ZSS

3PH HYD10000 ZSS / 3PH HYD15000 ZSS / 3PH HYD20000 ZSS

- **Scope**






This manual describes the assembly, installation, electrical connections, commissioning, maintenance and troubleshooting of the HYD 5-20KTL-3PH range of inverters.

Keep this manual so that it is accessible at all times.

- **Recipients**

This manual is intended for qualified technical personnel (installers, technicians, electricians, technical support personnel or anyone who is qualified and certified to operate a photovoltaic system), who are responsible for installing and starting up the inverter in the photovoltaic and storage energy plant and for operators of photovoltaic and storage systems.

- **Symbols used**

	Danger: indicates a hazardous situation which, if not resolved or avoided, could result in serious personal injury or death
Danger	
	Warning: indicates a hazardous situation which, if not resolved or avoided, could result in serious personal injury or death
Warning	
	Caution: indicates a hazardous situation which, if not resolved or avoided, could result in minor or moderate personal injury
Caution	
	Attention: indicates a potentially hazardous situation which, if not resolved or avoided, could result in damage to the system or other property
Attention	
	Note: provides important tips on correct and optimal operation of the product
Note	

1. Introduction

The 3PH HYD5000-HYD20000-ZSS hybrid inverter is used in photovoltaic systems with battery storage. The system can be combined with WeCo , Pylontech and Azzurro batteries supplied in kit form by ZCS Azzurro.

The basic operating scheme is shown in figure below, the inverter has direct access to the photovoltaic production and to the management of the batteries, so that they can be charged and discharged according to the current production needs and conditions and to the actual consumption.

It can also be connected to the Emergency Power Supply (EPS) and used to charge the battery as the main power source in case of off-grid operation or blackout.



Figure 1 - Diagram of a system with 3PH HYD5000-HYD20000-ZSS hybrid inverter

2. Preliminary safety instructions

Before installation, please read this manual carefully and make sure you fully understand its contents. The 3PH HYD5000-HYD20000-ZSS inverter strictly complies with the safety regulations if it is installed, connected and serviced according to the instructions in this manual. During installation, operation and maintenance, all operators must follow the local safety guidelines. Improper operation may result in electric discharges and/or damage to people and property, and will also void the Zucchetti Centro Sistemi S.p.A. warranty.

2.1. Safety Notes

Electrical installation and maintenance of the 3PH HYD5000-HYD20000-ZSS inverter must be carried out by competent persons in accordance with the local guidelines; qualified electricians and professionals must be duly certified and authorised.

According to national requirements, before connecting to the electricity grid, permission must be obtained from the local energy provider. All connections must be carried out by a qualified electrician.

DO NOT place explosive or flammable materials (e.g. gasoline, kerosene, diesel fuel, oil, wood, cotton or rags, etc.) near the batteries or the 3PH HYD5000-HYD20000-ZSS inverter.

Keep the inverter and batteries away from direct sunlight. Do not place the inverter and batteries near ovens, flames and other heat sources as they may catch fire and cause an explosion.

Keep children away from both the batteries and the 3PH HYD5000-HYD20000-ZSS inverter.

Do not open the front cover of the 3PH HYD5000-HYD20000-ZSS inverter. Opening the front cover will void the product warranty. Damage caused by improper installation/operation is NOT covered by the product warranty.

If you have any problems with the packaging that could damage the inverter or if you discover any visible damage, please notify the transport company immediately. If necessary, request assistance from an installer or from Zucchetti Centro Sistemi SpA.

Transport of the equipment, especially by road, must be carried out with vehicles suitable to protect the components (in particular, the electronic components) against violent knocks, humidity, vibrations, etc. Zucchetti Centro Sistemi S.p.A. shall NOT be responsible for any damage or loss caused by improper installation.

2.2. Assembly and maintenance notes

In case of maintenance or repair, contact your service centre. Contact your nearest distributor for information or assistance. DO NOT repair the device yourself, as this may cause injury or damage to property.

The inverter must be completely disconnected (BAT, PV and AC) during maintenance. Before maintenance, disconnect the AC connection first, then the battery and DC photovoltaic system (PV1 and PV2), and wait at least 5 minutes (capacitor discharge time) to avoid electric shock.

The inverter may reach high temperatures and have rotating parts inside during operation. Switch off the 3PH HYD5000-HYD20000-ZSS inverter and wait for it to cool down before performing any maintenance.


The inverter and batteries must be located in well-ventilated areas. Do not place the inverter in a cabinet or in an airtight or poorly ventilated location. This could be extremely hazardous to the performance and life of the system.

Use a multimeter to check the polarity and voltage of the battery before turning on the power, and to also check the PV voltage and polarity before closing the PV switch. Make sure that the connections are carried out according to the instructions in this manual and refer to the detailed installation notes available at www.zcsazzurro.com.

If you want to store the batteries without using them, disconnect them from the 3PH HYD5000-HYD20000-ZSS inverters and store in a cool, dry and well-ventilated area.
Secure the inverter to appropriate objects with sufficient load capacity (walls, PV brackets, etc.) and ensure that it is positioned vertically.

Attention: follow the rules below during installation/maintenance of the battery:

- a) Remove watches, rings and other metal objects;
- b) Only use tools with insulated handles;
- c) Wear rubber gloves and shoes;
- d) Do not place tools or metal objects on top of the battery;
- e) Turn off the inverter and batteries before connecting/disconnecting the battery terminals;
- f) Both the positive and negative polarities must be isolated from the ground.

	<p>Electromagnetic radiation from the inverter can be harmful to health! Do not stay closer than 20 cm to the inverter while it is on or operating.</p>
Danger	

Maintenance

The inverters do not require daily maintenance. The heat exchangers and cooling fans must not be obstructed or clogged by dust, dirt or other objects. Before cleaning, ensure that the DC switch is OFF, the battery is switched OFF and the switch between the inverter and mains grid is OFF; wait at least 5 minutes before cleaning.

To ensure good long-term functioning, check that there is enough space around the heat exchangers for air to pass through and that no dust, dirt, etc. accumulates.

Clean the inverter and heat exchangers with air, a soft dry cloth or soft-bristled brush. DO NOT clean the inverter and heat exchangers with water, corrosive substances, detergents, etc.



2.3. Symbols on the inverter

Labels must NOT be hidden by foreign objects and/or parts (rags, boxes, equipment, etc.); they must be clean to ensure legibility.









Figure 2 - Labels on the device

Some safety symbols are located on the inverter. Read and understand the content of the symbols before installing the inverter.

	<p>This symbol indicates a hazardous situation which, if not avoided, will result in injury</p>
	<p>Risk of electric shock; wait at least 5 minutes before opening the cover of the 3PH HYD5000-HYD20000-ZSS inverter.</p>
	<p>Beware of high voltage and electric shocks</p>
	<p>Beware of hot surfaces</p>
	<p>Complies with the European (EC) Conformity certification.</p>








	<p>Ground terminal</p>
	<p>Read this manual before installing the 3PH HYD5000-HYD20000-ZSS inverter</p>
	<p>This value indicates the degree of protection of the equipment in accordance with the IEC 70-1 (EN 60529 June 1997) standard.</p>
	<p>Positive and negative polarities of DC voltage (Photovoltaic and Battery)</p>
	<p>This side up. The 3PH HYD5000-HYD20000-ZSS inverter must always be transported, handled and stored in such a way that the arrows are always pointing upwards.</p>

Table 1 – Symbols on the device



3. Installation

The 3PH HYD5000-HYD20000-ZSS inverters are subjected to strict controls and inspection before packaging and delivery. Do not turn the inverter upside down during delivery.

 Caution	<p>Carefully check the packaging and product fittings before installation.</p>
---	---



Figure 3 - Installation process

The 3PH HYD5000-HYD20000-ZSS inverter can operate in automatic mode and in time-of-use charge, charge/discharge mode. In automatic mode, when the energy produced by the PV field is greater than that required by the utilities, the 3PH HYD5000-HYD20000-ZSS inverter charges the battery using the photovoltaic energy in excess, and when the photovoltaic energy is lower than that required, the inverter uses the energy stored in the battery to supply current to the local load.

3.1. Product overview

The 3PH HYD5000-HYD20000-ZSS storage inverters allow up to 10% overload to maximum power output and the Emergency Power Supply (EPS) mode can support inductive loads, such as air conditioners or refrigerators with an automatic switching time of less than 20 milliseconds.




Figure 4 - Inverter dimensions and accessories

Main product features:

- a. Double MPPT tracker with allowable DC overload of up to 1.5 times.
- b. Flexible and fast switching between on-grid and off-grid modes.
- c. Maximum efficiency of battery charging and discharging of 97.7%
- d. 2 battery input strings with maximum charge and discharge of 25A per string.
- e. Wide battery voltage range (200-700V).
- f. Off-grid output can be connected to an unbalanced load.
- g. Multi-parallel AC function, more flexible solution.
- h. Intelligent monitoring, RS485/Wi-Fi/Bluetooth/GPRS (optional).




Figure 5 - Inverter overview









1	Battery input terminals	7	DRMs (active management of limitations)*
2	DC Switch	8	COM
3	PV input terminals	9	Port 1 for parallel connection
4	Privileged load connection port	10	Port 0 for parallel connection
5	Grid connection port	11	CT (current sensors)
6	USB/Wi-Fi	12	LCD

* depends on national regulations










Table 2 - Inverter overview



3.2. Package contents

No.	Component		Qty
1		Inverter	1
2		Bracket	1
3		PV+ clamp terminals	4
4		PV- clamp terminals	4
5		Metal clamp terminals fixed to PV+ input power cables	4
6		Metal clamp terminals fixed to PV- input power cables	4
7		Metal clamp terminals fixed to BAT+ input power cables	2
8		Metal clamp terminals fixed to BAT- input power cables	2



9		2 M6 hexagonal screws	2
10		M8x80 expansion plugs to secure the bracket to the wall	4
11		AC Grid Connector	1
12		Critical load connector	1
13		Connection port connector (for parallel function)	2
14		Termination resistor	1
15		6-pin CT connector	1
16		Current sensor	3
17		16-pin COM connector	1









18		Manual	1
19		Warranty	1
20		Registration form	1

Table 3- Package contents









3.3. Requirements for the installation environment

	DO NOT install the 3PH HYD5000-HYD20000-ZSS on flammable material. DO NOT install the 3PH HYD5000-HYD20000-ZSS in an area used for the storage of flammable or explosive materials
Danger	
	The casing and heat sink are very hot while the inverter is running, therefore DO NOT install the 3PH HYD5000-HYD20000-ZSS in places where it can be accidentally touched
Caution	
	Consider the weight of the 3PH HYD5000-HYD20000-ZSS when transporting and moving the inverters. Choose an appropriate mounting position and surface. Assign at least two people to install the inverter
Attention	

The packaging materials and components can be damaged during transport. Therefore, check the outer packaging before installation; check that the materials are not damaged. In case of damage, contact the dealer as soon as possible.

It is recommended to remove the packing materials within 24 hours before installing the inverter.

3.4. Installation tools

No.	Tool	Model	Function
1		Drill (recommended: 6mm drill bit)	To make a hole in the wall
2		Screwdriver	To screw in the electrical circuits
3		Star screwdriver	To remove the AC terminal screws
4		Removal wrench	To remove the PV terminals
5		Wire stripper	To strip the wires
6		4mm hex key	To connect the bracket with the inverter
7		Crimping tool	To crimp the power cables
8		Multi-meter	To meter the ground protection









9		Marker	To mark the references
10		Tape measure	To measure distances
11		Level	To make sure the support is level and aligned correctly
12		ESD gloves	For the operator's protection
13		Safety goggles	For the operator's protection
14		Dust mask	For the operator's protection

Table 4 - Installation tools



3.5. Wall installation position

The inverter must be placed in a dry and clean place for proper functioning. The area must be tidy and convenient for installation, and well-ventilated to prevent overheating. **DO NOT** place it near flammable or explosive materials.

The AC overvoltage of the 3PH HYD5000-HYD20000-ZSS inverter belongs to Category III.

Maximum operating altitude: 2000 m.

Ambient temperature range: -25°C ~ 60°C.

Relative humidity: 0 ~ 100% (non-condensing).




Figure 6 - Correct positioning of the inverter (1)






Figure 7 - Correct positioning of the inverter (2)



3.6. Assembly instructions

To remove the inverter, open the packaging, insert your hands into the slots on both sides of the inverter and grasp the handles, lift the inverter out of the packaging and move it to the installation position.

	<p>The inverter is quite heavy, so make sure to keep your balance while moving it. Two or more people are needed to move the packaging and inverter.</p>
<p>Danger</p>	
	<p>When placing the inverter on the floor, place foam or paper under it to protect the housing.</p>
<p>Attention</p>	

1. Determine the position of the holes, make sure the positions of the holes are level, then mark them with a marker pen. Use the drill to make the holes on the wall. The drill must remain perpendicular to the wall. Try not shake it while drilling the holes so as not to damage the wall. If the holes are not level, they must be repositioned and drilled again.
2. Insert the expansion screws vertically into the hole, making sure that the insertion depth is neither too shallow nor too deep.
3. Align the bracket with the hole, and secure it by tightening the expansion bolts with nuts.
4. Position and fix the inverter to the rear panel.
5. (OPTIONAL) install an anti-theft lock.







Figure 8 - Positioning of the inverter on the wall

4. Electrical connections

Before making any electrical connections, make sure that the DC circuit breaker is switched off. The stored electrical charge remains in the capacitor after the DC circuit breaker has been switched off, for safety reasons, wait 5 minutes for the capacitor to discharge completely.

	The PV modules generate electricity when exposed to sunlight, and can create electric shocks. Therefore, before connecting the DC power cord, cover the PV modules with a dark covering.
Danger	
	The inverter must be installed and serviced by a professional electrician. Wear protection equipment when working on high voltage/high current systems such as inverters and battery systems.
Attention	
	For the 3PH HYD5000-HYD20000-ZSS inverter, the open-circuit voltage (Voc) of the strings related to the modules connected in series must be $\leq 1000V$
Note	

The PV modules must have an IEC 61730 classification of Class A.

Model	Isc PV (absolute maximum)	Maximum output overcurrent protection
3PH HYD5000 ZSS	15A/15A	8A*3
3PH HYD6000 ZSS		10A*3
3PH HYD8000 ZSS		13A*3
3PH HYD10000 ZSS	30A/30A	20A*3
3PH HYD15000 ZSS		25A*3
3PH HYD20000 ZSS		32A*3

Table 5 - Models of three-phase hybrid models

There are two ways to measure the currents exchanged with the grid; refer to the technical notes in the website www.zcsazzurro.com for more details.

1. Direct-insertion current sensors




Figure 9 - Configuration with CT current sensor

2. Meter + CT sensor








Figure 10 - Configuration with meter + CT sensor



Component	Description	Recommended cable type	Recommended cable specifications	
 <p>BAT1 BAT2</p>	+ : connection of the positive electrode to the lithium battery	Multi-core copper cable for outdoor use	Conductor with cross-section: 6mm²	
	- : connection of the negative electrode to the lithium battery			
 <p>PV1</p>	+ : connection of the positive electrode to the photovoltaic system	Outdoor industrial cable for photovoltaic systems	Conductor with cross-section: 6mm²	
	- : connection of the negative electrode to the photovoltaic system			
 <p>PV2</p>	+ : connection of the positive electrode to the photovoltaic system	Outdoor industrial cable for photovoltaic systems	Conductor with cross-section: 6mm²	
	- : connection of the negative electrode to the photovoltaic system			
	Load	L1	Multi-core copper cable for outdoor use	Conductor with cross-section: 6mm²~10mm²
		L2		
		L3		
		N		
		PE		





	AC	L1	Multi-core copper cable for outdoor use	Conductor with cross-section: 10mm²~16mm²
		L2		
		L3		
		N		
		PE		

Table 6 - Cable specifications

4.1. Connection of protective ground cables (PGND)

Connect the inverter and the batteries to the grounding electrode using protective ground cables (PGND).

	<p>The inverter does not have a transformer, therefore the positive and negative polarities of the PV array do NOT have to be grounded. All the metal parts in the photovoltaic supply system that do not carry current must be grounded (e.g. PV module frame, PV bracket, dialler housing, inverter housing).</p>
Attention	

The PGND cables are pre-set cables (external power supply cables $\geq 4\text{mm}^2$ are recommended for grounding purposes), the cable must be a yellow-green colour.

Procedure:

1. Remove a suitable length of the insulating layer using a wire stripper, **NB:** L2 is 3mm longer than L1.




Figure 11 - Removal of insulating layer



2. Insert the exposed core wires into the OT terminal and crimp them using a crimping tool.




Figure 12 - Crimping of the exposed core

3. Install the crimped OT terminal, insert the M5 screw and tighten the screw at a torque of 3Nm using the hex key.

NB: L3 is the length between the insulating layer of the ground cable, the L4 curved part and the core wires protruding from the secured part.

NB: The cavity formed on the conductor just below the crimping strip must completely wrap the core wires, which must be in contact with the terminal.




Figure 13 - Installation of crimped terminal

4.2. Connecting to grid

The inverter is equipped with an integrated unit for monitoring the residual current; when the inverter detects that the residual current exceeds 300mA, the connection to the grid will be quickly disconnected.

Procedure:

1. Select the type of cable and the appropriate specifications according to
2. Table 6.
3. Pass the cable through the terminal.




Figure 14 - Passing the wire through the terminal

4. Connect the cable to the terminal, according to the identification on the terminal.




Figure 15 - Connecting the wire to the terminal

5. Connect the terminal to the inverter port and turn the clamp in a clockwise direction.




Figure 16 - Connecting the terminal to the machine

4.3. Connecting to the load circuit

Procedure:

1. Select the type of cable and the appropriate specifications according to
2. Table 6.
3. Pass the wire through the terminal.




Figure 17 - Passing the wire through the terminal

4. Connect the cable to the terminal, according to the identification on the terminal.




Figure 18 - Connecting the cable to the terminal

5. Connect the terminal to the machine port and turn the clamp in a clockwise direction.




Figure 19 - Terminal clamping




4.4. Photovoltaic connection

Recommended specifications for DC input cables

Cross section (mm ² / AWG)		Outer diameter of cable (mm ²)
Range	Recommended value	
4.0-6.0 / 11-9	4.0 / 11	4.5~7.8

Procedure:


Step 1: Prepare the positive and negative photovoltaic cables.



1. Contatto positivo 2. Contatto negativo

Figure 20 - Preparing the positive and negative photovoltaic cables

Step 2: Insert the crimped positive and negative cables into the corresponding photovoltaic connectors.



3. Connettore positivo 4. Connettore negativo

Figure 21 - Preparing the positive and negative photovoltaic connectors

Step 3: Make sure that the DC voltage of each photovoltaic string is less than 1000 VDC and that the polarities of the photovoltaic cables are correct. Insert the positive and negative connectors into the inverter until you hear a "click" sound.





Figure 22 – Connecting the photovoltaic connectors

	<p>Before removing the positive and negative connectors, make sure that the DC circuit breaker is OPEN (OFF position).</p>
<p>Caution</p>	

Removal procedure

Use a MC4 wrench to disconnect the photovoltaic connectors.





Figure 23 – Disconnecting the photovoltaic connectors

Connect the inverter to the photovoltaic strings using DC input power cables.


To configure the inverter channels correctly:

1. Press the first button on the left of the display:




2. Press the last arrow on the right (enter) to access the basic settings:

1. Basic settings
2. Advanced settings
3. Production statistics
4. System Info
5. Event list
6. SW Update



3. Basic settings, press the down arrow until the channel configuration item is highlighted. Now press the last arrow to the right to access the channel configuration:

1. Language
2. Date and Time
3. Safety parameters
4. Working mode
5. Self-Test
6. Channel configuration
7. EPS Mode
8. Communication address



4. Configure channels as described below:

Inverter channels	Inverter channel configurations
Channel 1 input	Bat input 1
	Bat input 2
	Not used
Channel 2 input (only for inverters larger than 8kW)	Bat input 1
	Bat input 2
	Not used
Channel 3 input	PV input 1
	PV input 2
	Not used
Channel 4 input	PV input 1
	PV input 2
	Not used



For photovoltaic systems, set the inputs according to the string configuration, specifically:

- For independent strings, set:
 - Channel 3 input – PV input 1;
 - Channel 4 input – PV input 2.
- For parallel strings, set:
 - Channel 3 input – PV input 1;
 - Channel 4 input – PV input 1.

The inverter has two MPPTs, which can operate independently or in parallel. The user can choose the appropriate MPPT operating mode depending on how the system is designed.

Independent mode (default):

If the strings are different (e.g. installed on two separate flaps or consisting of a different number of panels), the input channels must be set to “independent mode.”

Parallel mode:

If the strings are connected in parallel, the channels must be configured in parallel.

Note:

Depending on the type of inverter, select the appropriate inverter accessories (cables, fuse holders, fuses, switches, etc.). The open-circuit voltage of the photovoltaic system must be lower than the maximum DC input voltage of the inverter. The output voltage of the strings must be compatible with the MPPT voltage range.

The positive and negative polarities of the panel on the inverter must be connected separately. The power supply cable must be suitable for photovoltaic applications.

Note:

Both MPPT inputs of the inverter must be populated, even if the system only has one string. If the strings are arranged in parallel, it is recommended to use a Y or T connection cable to double the input currents from the PV array and to populate both MPPT inputs of the inverter, as shown in the figure. If the string arrangement is independent, simply connect the two strings to the two MPPTs of the inverter.



Figure 24 – Y connection cable for solar panels



4.5. Connecting the battery

!!!PLEASE NOTE!!!

If the storage capacity of an existing system needs to be increased by adding one or more batteries, contact the Zucchetti pre-sales department in order to determine what charge percentage to bring all the batteries (installed and to be installed).

Connect the existing batteries one at a time to the inverter in order to check the charge status on the display (all the instantaneous information can be accessed by pressing the “Down” key from the main menu).

If the charge level and the voltage of the existing batteries are lower than the new one, they can be charged from excess photovoltaic production or by using the forced charge mode indicated in the “% charge mode” section of this manual.

4.2.1. Installing Pylontech batteries

4.2.1.1. Connecting a single battery tower



Figure 25 - Single battery tower



Each tower of battery modules consists of a BMS connected in series to multiple battery modules.

The devices to be used are:

1. The external BMS with 4 to 8 battery modules (ZST-BMS-SC500-H)




Figure 26 - SC500 BMS

2. The external BMS with 4 to 12 battery modules (ZST-BMS-SC1000-H)




Figure 27 - SC1000 BMS

3. The external Wi-Fi/USB BMS with 4 to 8 battery modules (ZST-BMS-SC500-H)




Figure 28 - Wi-Fi/USB SC500 BMS

4. The external Wi-Fi/USB BMS with 5 to 12 battery modules (ZST-BMS-SC1000-H)




Figure 29 – Wi-Fi/USB SC1000 BMS

5. Battery modules (ZST-BAT-2.4KWH-H)



Figure 30 - Battery module to be connected in series

4.2.1.2. Communication between the BMS and Battery Modules

The communication connections must be arranged as follows, using the communication cables between battery modules:

- Link port 1 of the BMS to link port 0 of the first battery
- Link port 1 of the first battery must be connected to link port 0 of the second
...
- Link port 1 of the second-last battery must be connected to link port 0 of the last battery.




Figure 31 - Communication connections: The BMS and the first battery module (left), connection between the battery modules (centre), connection between the second-last and last battery module in the series (right)



4.2.1.3. BMS and Inverter communication




Figure 32 - Hybrid inverter and BMS communication connection

The position of the dip switches in case of a single tower requires moving all the pins down, this means the address equals 000000.




Figure 33 - 000000 battery address

For communication between the battery and inverter, use the black communication cable supplied, which has the BAT and INV labels on the RJ45 end. On the BMS side, the end labelled BAT must be inserted into link port B. The other end, labelled INV, must be cut leaving only the wires connected to pins 2 (orange wire), 4 (blue wire) and 5 (white-blue wire) in the appropriate communication counterpart of the hybrid inverter.




Figure 34 - CAN input of the SC500 and SC1000 BMS




Figure 35 - CAN input of the Wi-Fi/USB SC500 and Wi-Fi/USB SC1000 BMS

Definition of RJ45 Port Pin

No.	CAN	RS485	RS232 Pin
1	---	---	---
2	GND	---	---
3	---	---	TX
4	CANH	---	---
5	CANL	---	---
6	---	GND	RX
7	---	RS485A	---
8	---	RS485B	GND



RJ45 Port



RJ45 Plug

Figure 36 - Pin Out CAN BMS input




Figure 37 - "Screw-in" COM port connection




Figure 38 - "Snap-in" COM port connection





Inverter PIN	Battery communication	Notes
7	CAN H (blue wire)	Communication with the BMS of the lithium battery, the CAN of the inverter adapts to the BMS of the lithium battery.
8	CAN L (white-blue wire)	
9	GND.S (orange wire)	




Figure 39 - "Screw-in" COM connection diagram




Figure 40 - "Snap-in" COM connection diagram

4.2.1.4. Power connections

The battery modules must be connected to each other in series via the cables shown in the figure below. The connection cables are supplied with the battery.



Figure 41 - Power connector between battery modules

The connector must be connected from the negative input of the first battery module to the positive input of the second one. The negative input of the second battery module must then be connected to the positive input of the third module, continuing the series until the negative input of the second-last module is connected to the positive input of the last module.

In this configuration, the positive input of the first module and the negative input of the last battery module will remain free (use the colour of the connector as a reference).



Figure 42 - Power cable between battery modules



Subsequently, the external BMS must be connected to the series of battery modules. Therefore the positive of the BMS must be connected to the positive of the first battery, and the negative of the BMS to the negative of the last battery module (the cables for this connection are supplied with the BMS).



Figure 43 - Connection cables between the BMS and battery modules



Figure 44 - Power connection (positive) between the BMS and first battery module



Figure 45 - Power connection (negative) between the BMS and the last battery module



Finally, the BMS must be connected to the inverter via the power cables provided in the kit (ZST-CABLE-KIT-H) as shown in the figure.



Figure 46 - BMS Inverter power cables (left), inverter-side power terminals (centre), battery-side power terminals (left)




Figure 47 - BMS power connection




Figure 48 - Inverter-side DC power connection with a single battery input populated




4.2.1.5. Channel configuration (single Pylontech tower)

To configure the inverter channels correctly:


5. Press the first button on the left of the display:



6. Press the last arrow on the right (enter) to access the basic settings:



7. Basic settings, press the down arrow until the channel configuration item is highlighted. Now press the last arrow to the right to access the channel configuration:



8. Configure channels as described below:




Inverter channels	Inverter channel configurations
Channel 1 input	Bat input 1
	Bat input 2
	Not used
Channel 2 input (only for inverters larger than 8kW)	Bat input 1
	Bat input 2
	Not used
Channel 3 input	PV input 1
	PV input 2
	Not used
Channel 4 input	PV input 1
	PV input 2
	Not used


Set the battery inputs according to the configuration of the towers, specifically, with only one Pylontech BMS connected to the inverter:

- Input channel 1 – BAT input 1;
- Input channel 2 – Not used.


9. Once the channels have been correctly configured, enter the advanced settings by pressing the last button on the right of the inverter (enter password: 0715):



10. Enter the battery settings by pressing the last button on the right of the inverter:



11. Enter the Battery 1 item by pressing the last button on the right of the inverter:



12. Set the parameters as follows:

BATTERY 1	
1.Battery type	Pylon
2.Battery address	00
3.Maximum charge (A)	25.00A
4.Maximum discharge (A)	25.00A
5.Depth of Discharge	80%
6.Save	



4.2.1.6. Installation with two battery towers (with SC500 and SC1000 BMS)



Figure 49 - Two battery towers

4.2.1.7. Communication between the BMS (SC500 and SC1000) and Battery Modules

The communication connections must be arranged for each tower as shown in the previous sections, using the communication cables between the battery modules:

- Link port 1 of the BMS to link port 0 of the first battery
- Link port 1 of the first battery must be connected to link port 0 of the second
- ...
- Link port 1 of the second-last connected to the last.

BMS (SC500 and SC1000) – Inverter communication

The two BMS must be set with a different address by changing the position of the dip switches, as shown below:

- Address 000000 = address 0 (to be assigned to tower 1)
- Address 100001 = address 1 (to be assigned to tower 2)

The RJ45 cable of the BMS with Address=1 (tower 2) will depart from the link port B of the CAN/RS485 input and connect to the link port A of the CAN/RS485 input of the BMS with Address=0 (tower 1); finally, another cable must be inserted in link port B of the same BMS and must be connected to the COM of the inverter, in the same way as indicated in the previous section.




Figure 50 - Communication connections between battery towers

Inverter side

Connect the cable in position 4 (blue wire) to position 7 of the communication connector supplied with the inverter (see figure below).
 Connect the cable in position 5 (white-blue wire) to position 8 of the communication connector supplied with the inverter (see figure below).
 Connect the cable in position 2 (orange wire) to position 9 of the communication connector supplied with the inverter (see figure below).




Figure 51 - Section of inverter connections




Figure 52 - "Screw-in" COM port connection




Figure 53 - "Snap-in" COM port connection





Inverter PIN	Battery communication	Notes
7	CAN H (blue wire)	Communication with the BMS of the lithium battery, the CAN of the inverter adapts to the BMS of the lithium battery.
8	CAN L (white-blue wire)	
9	GND.S (orange wire)	




Figure 54 - "Screw-in" COM connection diagram




Figure 55 - "Snap-in" COM connection diagram

4.2.1.8. Power connections (SC500 and SC1000 BMS)

The power cables in each tower between the battery modules and the BMS must be connected as indicated in the previous section.

As for the connection between each tower and the inverter, the two power cables (+ and -) coming from each BMS will be connected to the two inputs of the inverter: BAT1 and BAT2



Figure 56 - Inverter-side DC power connection with two battery inputs populated


Identify the two battery towers by assigning the number 1 to the tower connected to channel 1 and number 2 to the tower connected to channel 2.




4.2.1.9. Channel configuration of Pylontech dual tower (SC500 and SC1000)

To configure the inverter channels correctly:


1. Press the first button on the left of the display:



2. Press the last arrow on the right (enter) to access the basic settings:



3. Basic settings, press the down arrow until the channel configuration item is highlighted. Now press the last arrow to the right to access the channel configuration:




4. Configure channels as described below:

Inverter channels	Inverter channel configurations
Channel 1 input	Bat input 1
	Bat input 2
	Not used
Channel 2 input (only for inverters larger than 8kW)	Bat input 1
	Bat input 2
	Not used
Channel 3 input	PV input 1
	PV input 2
	Not used
Channel 4 input	PV input 1
	PV input 2
	Not used


Set the battery inputs according to the configuration of the towers, specifically, with two Pylontech Battery Management Systems connected to the inverter:

- Input channel 1 – BAT input 1;
- Input channel 2 – BAT input 2.


5. Once the channels have been configured correctly, enter the advanced settings by pressing the last button on the right of the inverter (enter password: 0715):



6. Enter the battery settings by pressing the last button on the right of the inverter:



7. Enter the Battery 1 item by pressing the last button on the right of the inverter:




8. Set the parameters as follows:

BATTERY 1	
1. Battery type	Pylon
2. Battery address	00
3. Maximum charge (A)	25.00A
4. Maximum discharge (A)	25.00A
5. Depth of Discharge	80%
6. Save	



9. Enter the Battery 2 item by pressing the last button on the right of the inverter:



10. Set the parameters as follows:

BATTERY 2	
1. Battery type	Pylon
2. Battery address	01
3. Maximum charge (A)	25.00A
4. Maximum discharge (A)	25.00A
5. Depth of Discharge	80%
6. Save	



4.2.1.10. Installation with two battery towers (with Wi-Fi/USB SC500 and Wi-Fi/USB SC1000 BMS)




Figure 57 - Two battery towers

4.2.1.11. Communication between BMS (Wi-Fi/USB SC500 and Wi-Fi/USB SC1000) and Battery Modules

The communication connections must be arranged for each tower as shown previously, using the communication cables between the battery modules:

- Link port 1 of the BMS to link port 0 of the first battery
- Link port 1 of the first battery must be connected to link port 0 of the second
- ...
- Link port 1 of the second-last battery must be connected to link port 0 of the last battery.



BMS (Wi-Fi/USB SC500 and Wi-Fi/USB SC1000) Communication - Inverter

The two BMSs must be set with a different address by changing the position of the dip switches, as shown below:

- Address 100001 = address 1 (to be assigned to tower 1)
- Address 010001 = address 1 (to be assigned to tower 2)

From the CAN input of the BMS with Address=010001 (tower 2) will start an RJ45 cable until it connects to the COM port of the inverter.

From the CAN input of the BMS with Address=100001 (tower 1) will start an RJ45 cable until it connects to the COM port of the inverter.




Figure 58 - Communication connections between battery towers

BMS with Address=010001 (tower 2)

Connect the cable in position 4 (blue wire) to position 7 of the communication connector supplied with the inverter (see figure below).

Connect the cable in position 5 (white-blue wire) to position 8 of the communication connector supplied with the inverter (see figure below).

Connect the cable in position 2 (orange wire) to position 9 of the communication connector supplied with the inverter (see figure below).

BMS with Address=100001 (tower1)

Connect the cable in position 4 (blue wire) to position 7 of the communication connector supplied with the inverter (see figure below).

Connect the cable in position 5 (white-blue wire) to position 8 of the communication connector supplied with the inverter (see figure below).

Connect the cable in position 2 (orange wire) to position 9 of the communication connector supplied with the inverter (see figure below).




Figure 59 - Section of inverter connections




Figure 60 - "Screw-in" COM port connection




Figure 61 - "Snap-in" COM port connection





Inverter PIN	Battery communication	Notes
7	CAN H (blue wire)	Communication with the BMS of the lithium battery, the CAN of the inverter adapts to the BMS of the lithium battery.
8	CAN L (white-blue wire)	
9	GND.S (orange wire)	




Figure 62 - "Screw-in" COM connection diagram




Figure 63 - "Snap-in" COM connection diagram

4.2.1.12. Power connections (Wi-Fi/USB SC500 and Wi-Fi/USB SC1000 BMS)

The power cables in each tower between the battery modules and the BMS must be connected as indicated above.

As for the connection between each tower and the inverter, the two power cables (+ and -) coming from each BMS will be connected to the two inputs of the inverter: BAT1 and BAT2



Figure 64 - Inverter-side DC power connection with two battery inputs populated

Identify the two battery towers by assigning the number 1 to the tower connected to channel 1 and number 2 to the tower connected to channel 2.




4.2.1.13. Channel configuration (two Pylontech towers - Wi-Fi/USB SC500 and Wi-Fi/USB SC1000)

To configure the inverter channels correctly:


1. Press the first button on the left of the display:



2. Press the last arrow on the right (enter) to access the basic settings:



3. Basic settings, press the down arrow until the channel configuration item is highlighted. Now press the last arrow to the right to access the channel configuration:




4. Configure channels as described below:

Inverter channels	Inverter channel configurations
Channel 1 input	Bat input 1
	Bat input 2
	Not used
Channel 2 input (only for inverters larger than 8kW)	Bat input 1
	Bat input 2
	Not used
Channel 3 input	PV input 1
	PV input 2
	Not used
Channel 4 input	PV input 1
	PV input 2
	Not used


Set the battery inputs according to the configuration of the towers, specifically, with two Pylontech Wi-Fi/USB Battery Management Systems connected to the inverter:

- Input channel 1 – BAT input 1;
- Input channel 2 – BAT input 2.


5. Once the channels have been configured correctly, enter the advanced settings by pressing the last button on the right of the inverter (enter password: 0715):



6. Enter the battery settings by pressing the last button on the right of the inverter:



7. Enter the Battery 1 item by pressing the last button on the right of the inverter:




8. Set the parameters as follows:

BATTERY 1	
1. Battery type	Pylon
2. Battery address	01
3. Maximum charge (A)	25.00A
4. Maximum discharge (A)	25.00A
5. Depth of Discharge	80%
6. Save	



9. Enter the Battery 2 item by pressing the last button on the right of the inverter:



10. Set the parameters as follows:

BATTERY 2	
1. Battery type	Pylon
2. Battery address	02
3. Maximum charge (A)	25.00A
4. Maximum discharge (A)	25.00A
5. Depth of Discharge	80%
6. Save	





4.2.2. WeCo 5K3 battery installation

4.2.2.1. Only one 5K3 battery tower connected




Figure 65 - Single battery tower



Each tower consists of an HV-BOX connected in series to multiple battery modules.
The devices to be used are:

- external HV BOX




Figure 66 - HV BOX

- Battery module




Figure 67 - Battery module to be connected in series




4.2.2.2. Communication between HV BOX and 5K3 Battery Modules

The communication connections must be arranged as follows, using the communication cables between the battery modules:

- CAN1-B of the HV BOX to CAN-A of the first battery
- LINK of the HV BOX to LINK-A of the first battery
- CAN-B of the first battery to CAN-A of the second battery
- LINK-B of the first battery to LINK-A of the second battery
- ...
- CAN-B of the second-last battery to CAN-A of the last battery
- LINK-B of the second-last battery to LINK-A of the last battery.

As regards the positioning of the dip switches of the battery tower, it is necessary to first check the serial number of the HV BOX module and select the address according to the following indications:

- The DIP switches of all the battery modules except for the last one must be set so that the addresses from 1 to 5 are in the ON position, while those from 6 to 8 are in the OFF position (ADD=11111000).
- The last module in the series must have all pins set to ON, except for pins 1, 6, and 8 which must be set to OFF (ADD=01111010)

Battery modules from first to second-last battery	
Last battery in the series	

Connect all battery and HV-BOX grounds to the ground system via appropriate terminals.




Figure 68 - Communication connections: HV BOX and first battery module, connection between battery modules, connection between second-last and last battery module in the series



4.2.2.3. 5K3 HV BOX and Inverter communication




Figure 69 - HV BOX configuration

In the case of a single battery tower, the address must be set with all pins in the OFF position, except for pin 7, which must be in the ON position.

The inverter and the HV BOX must be connected by populating the CAN2-A input with the Inverter-HV BOX communication cable. The other end, in which only the “orange” and “white-orange” wires are present, must be wired to the quick-connect COM connector of the hybrid inverter, as shown in the figures below.

The HV BOX must be grounded using the M5 screw terminals supplied.




Figure 70 - Inverter/HV BOX communication cable






Figure 71 - Section of inverter connections




Figure 72 - "Screw-in" COM port connection




Figure 73 - "Snap-in" COM port connection





Inverter PIN	Battery communication	Notes
7	CAN H (white-orange wire)	Communication with the HV BOX of the lithium battery, the CAN of the inverter adapts to the HV BOX of the lithium battery.
8	CAN L (orange wire)	




Figure 74 - "Screw-in" COM interface description




Figure 75 - "Snap-in" COM connection diagram



4.2.2.4. 5K3 power connections

The battery modules must be connected in series via the cables supplied.

The connector must be connected from the negative input of the first battery to the positive input of the second one. From here, the negative input must be connected to the positive input of the third module, continuing the series until the negative input of the second-last module is connected to the positive input of the last module.

In this configuration, the positive input of the first module and the negative input of the last battery will remain free (use the colour of the connector as a reference).




Figure 76 - Power wiring between battery modules in series

Subsequently, the HV BOX must be connected respecting the + and – polarity as it is powered by the batteries themselves. Therefore, the positive of the HV BOX must be connected to the positive of the first battery, and the negative of the HV BOX to the negative of the last battery module.

The HV BOX must be grounded using the M5 screw terminals supplied.

Connect all the grounds to the ground system using the appropriate connector.




Figure 77 - HV BOX power connection

As for the power connections between the HV BOX and the inverter, the HV BOX module allows the connection of both channels coming from the inverter (if properly set, the battery column will be able to manage the maximum power of the inverter, both when charging and discharging).




Figure 78 - Inverter-side DC power connection with two battery inputs populated




4.2.2.5. Channel configuration (single WeCo 5K3 tower)

To configure the inverter channels correctly:


1. Press the first button on the left of the display:



2. Press the last arrow on the right (enter) to access the basic settings:



3. Basic settings, press the down arrow until the channel configuration item is highlighted. Now press the last arrow to the right to access the channel configuration:




4. Configure channels as described below:

Inverter channels	Inverter channel configurations
Channel 1 input	Bat input 1
	Bat input 2
	Not used
Channel 2 input (only for inverters larger than 8kW)	Bat input 1
	Bat input 2
	Not used
Channel 3 input	PV input 1
	PV input 2
	Not used
Channel 4 input	PV input 1
	PV input 2
	Not used


As for the batteries, setting the inputs according to the configuration of the towers, specifically, with only one WeCo HVBOX connected to the inverter, it is possible:

1. For HYD 5000 ZSS/HYD 8000 ZSS inverter (single battery input):
 - Input channel 1 – BAT input 1;
 - Input channel 2 – Not used.
 2. For HYD 10000 ZSS/HYD 20000 ZSS inverter (dual battery input):
 - Input channel 1 – BAT input 1;
 - Input channel 2 – BAT input 1.
5. Once the channels have been configured correctly, enter the advanced settings by pressing the last button on the right of the inverter (enter password: 0715):




6. Enter the battery settings by pressing the last button on the right of the inverter:

1. Battery parameters
2. Feed-in limit
3. IV Curve Scan
4. Logic interface
5. Factory reset
6. Parallel settings
7. Reset Bluetooth
8. CT Calibration
9. On-Off switch



7. Enter the Battery 1 item by pressing the last button on the right of the inverter:

1. Battery 1



8. Set the parameters as follows:

HYD 5000 ZSS/HYD 8000 ZSS	
BATTERY 1	
1. Battery type	WeCo
2. Battery address	00
3. Maximum charge (A)	25.00A
4. Maximum discharge (A)	25.00A
5. Depth of Discharge	80%

HYD 10000 ZSS/HYD 20000 ZSS	
BATTERY 1	
1. Battery type	WeCo
2. Battery address	00
3. Maximum charge (A)	50.00A
4. Maximum discharge (A)	50.00A
5. Depth of Discharge	80%



4.2.2.6. Installation with two battery towers 5K3




Figure 79 - Two battery towers



4.2.2.7. Communication between HV BOX and 5K3 Battery Modules

The communication connections must be arranged for each tower as shown in the previous sections, using the communication cables between the battery modules:

- CAN1-B of the HV BOX to CAN-A of the first battery
- LINK of the HV BOX to LINK-A of the first battery
- CAN-B of the first battery to CAN-A of the second battery
- LINK-B of the first battery to LINK-A of the second battery
- ...
- CAN-B of the second-last battery to CAN-A of the last battery
- LINK-B of the second-last battery to LINK-A of the last battery.
-

Connect all battery and HV-BOX grounds to the ground system via appropriate terminals.

4.2.2.8. 5K3 HV BOX – Inverter communication

In the case of two battery towers:

1. Battery Tower 1
 - a. All pins in the OFF position, except pin 1, which must be in the ON position (ADD=00000010).
2. Battery Tower 2
 - a. All pins in the OFF position, except pin 7, which must be in the ON position (ADD=10000000).

A cable from the CAN2-B input of the HV BOX of tower 1 must be connected to the CAN2-B input of the HV BOX of tower 2; finally, the Inverter/HV BOX communication cable must be inserted in the CAN2-A port of the HV BOX.




Figure 80 - Communication connections between battery towers

The inverter and the HV BOX must be connected by populating the CAN2-A input with the Inverter-HV BOX communication cable. The other end, in which only the “orange” and “white-orange” wires are present, must be wired to the quick-connect COM connector of the hybrid inverter, as shown in the figures below.

The HV BOX must be grounded using the M5 screw terminals supplied.




Figure 81 - Inverter/HV BOX communication cable




Figure 82 - Section of inverter connections






Figure 83 - "Screw-in" COM port connection




Figure 84 - "Snap-in" COM port connection





Inverter PIN	Battery communication	Notes
7	CAN H (white-orange wire)	Communication with the HV BOX of the lithium battery, the CAN of the inverter adapts to the HV BOX of the lithium battery.
8	CAN L (orange wire)	




Figure 85 - "Screw-in" COM interface description




Figure 86 - "Snap-in" COM connection diagram



4.2.2.9. Power connections with two 5K3 battery towers

The power cables in each tower between the battery modules and the HV BOX must be connected as indicated above.

As for the connection between each tower and the inverter, the two power cables (+ and -) coming from the HV BOX will be connected to the two inputs of the inverter: BAT1 and BAT2.

Connect all the grounds to the ground system using the appropriate connector.



Figure 87 - Inverter-side DC power connection with two battery inputs populated

Identify the two battery towers by assigning the number 1 to the tower connected to channel 1 and number 2 to the tower connected to channel 2.




4.2.2.10. Channel configuration (dual WeCo 5K3 tower)

To configure the inverter channels correctly:


1. Press the first button on the left of the display:



2. Press the last arrow on the right (enter) to access the basic settings:



3. Basic settings, press the down arrow until the channel configuration item is highlighted. Now press the last arrow to the right to access the channel configuration:




4. Configure channels as described below:

Inverter channels	Inverter channel configurations
Channel 1 input	Bat input 1
	Bat input 2
	Not used
Channel 2 input (only for inverters larger than 8kW)	Bat input 1
	Bat input 2
	Not used
Channel 3 input	PV input 1
	PV input 2
	Not used
Channel 4 input	PV input 1
	PV input 2
	Not used


Set the battery inputs according to the configuration of the towers, specifically, with two WeCo HV BOXES connected to the inverter:

- Input channel 1 – BAT input 1;
- Input channel 2 – BAT input 2.


5. Once the channels have been configured correctly, enter the advanced settings by pressing the last button on the right of the inverter (enter password: 0715):



6. Enter the battery settings by pressing the last button on the right of the inverter:



7. Enter the Battery 1 item by pressing the last button on the right of the inverter:




8. Set the parameters as follows:

BATTERY 1	
1. Battery type	WeCo
2. Battery address	00
3. Maximum charge (A)	25.00A
4. Maximum discharge (A)	25.00A
5. Depth of Discharge	80%
6. Save	



9. Enter the Battery 2 item by pressing the last button on the right of the inverter:



10. Set the parameters as follows:

BATTERY 2	
1. Battery type	WeCo
2. Battery address	01
3. Maximum charge (A)	25.00A
4. Maximum discharge (A)	25.00A
5. Depth of Discharge	80%
6. Save	





4.2.3. WeCo 5K3XP battery installation

4.2.3.1. Only one 5K3XP battery tower connected




Figure 88 - Single battery tower



Each tower consists of a HV-BOX connected in series to multiple battery modules. The devices to be used are:

3. external HV BOX



Figure 89 - HV BOX

4. Battery module




Figure 90 - Battery module to be connected in series





4.2.3.2. 5K3XP HV BOX and 5K3XP Battery Modules communication

The communication connections must be arranged as follows, using the communication cables between the battery modules:

- CAN1-B of the HV BOX to CAN-A of the first battery
- CAN-B of the first battery to CAN-A of the second battery
- ...
- CAN-B of the second-last battery to CAN-A of the last battery

As regards the positioning of the dip switches of the battery tower, first check the serial number of the HV BOX module and select the address according to the following indications:

- The DIP switches of all the battery modules except for the last one must be set so that the addresses from 1 to 5 are in the ON position, while those from 6 to 8 are in the OFF position (ADD=11111000).
- The last module in the series must have all pins set to ON, except for pins 1, 6, and 8 which must be set to OFF (ADD=01111010)

Battery modules from first to second-last battery	
Last battery in the series	

Connect all the ground masses of the batteries and HV-BOX to the ground system via appropriate terminals.




Figure 91 - Communication connections: HV BOX and first battery module, connection between battery modules, connection between second-last and last battery module in the series



4.2.3.3. 5K3XP HV BOX and Inverter communication




Figure 92 - HV BOX configuration

In the case of a single battery tower, the address must be set with all pins in the OFF position, except for pin 7, which must be in the ON position.

The inverter and the HV BOX must be connected by populating the CAN2-A input with the Inverter-HV BOX communication cable. The other end, in which only the “orange” and “white-orange” wires are present, must be wired to the quick-connect COM connector of the hybrid inverter, as shown in the figures below.

The HV BOX must be grounded using the M5 screw terminals supplied.




Figure 93 - Inverter/HV BOX communication cable




Figure 94 - Section of inverter connections




Figure 95 - "Screw-in" COM port connection




Figure 96 - "Snap-in" COM port connection



Inverter PIN	Battery communication	Notes
7	CAN H (white-orange wire)	Communication with the HV BOX of the lithium battery, the CAN of the inverter adapts to the HV BOX of the lithium battery.
8	CAN L (orange wire)	




Figure 97 - "Screw-in" COM interface description




Figure 98 - "Snap-in" COM connection diagram

4.2.3.4. 5K3XP power connections

The battery modules must be connected in series via the cables supplied.

The connector must be connected from the negative input of the first battery to the positive input of the second one. From here, the negative input must be connected to the positive input of the third module, continuing the series until the negative input of the second-last module is connected to the positive input of the last module.

In this configuration, the positive input of the first module and the negative input of the last battery will remain free (use the colour of the connector as a reference).




Figure 99 - Power wiring between battery modules in series

Subsequently, the HV BOX must be connected respecting the + and – polarity as it is powered by the batteries themselves. Therefore, the positive of the HV BOX must be connected to the positive of the first battery, and the negative of the HV BOX to the negative of the last battery module.

The HV BOX must be grounded using the M5 screw terminals supplied.

Connect all the grounds to the ground system using the appropriate connector.




Figure 100 - HV BOX power connection

As for the power connections between the HV BOX and the inverter, the HV BOX module allows the connection of both channels coming from the inverter (if properly set from the inverter LCD, the battery column will be able to manage the maximum power of the inverter, both when charging and discharging).



Figure 101 - Inverter-side DC power connection with two battery inputs populated


4.2.3.5. Channel configuration (single WeCo 5K3XP tower)

To configure the inverter channels correctly:


1. Press the first button on the left of the display:



2. Press the last arrow on the right (enter) to access the basic settings:



3. Basic settings, press the down arrow until the channel configuration item is highlighted. Now press the last arrow to the right to access the channel configuration:




4. Configure channels as described below:

Inverter channels	Inverter channel configurations
Channel 1 input	Bat input 1
	Bat input 2
	Not used
Channel 2 input (only for inverters larger than 8kW)	Bat input 1
	Bat input 2
	Not used
Channel 3 input	PV input 1
	PV input 2
	Not used
Channel 4 input	PV input 1
	PV input 2
	Not used


As for the batteries, setting the inputs according to the configuration of the towers, specifically, with only one 5K3XP WeCo HVBOX connected to the inverter, it is possible:

3. For HYD 5000 ZSS/HYD 8000 ZSS inverter (single battery input):
 - Input channel 1 – BAT input 1;
 - Input channel 2 – Not used.
4. For HYD 10000 ZSS/HYD 20000 ZSS inverter (dual battery input):
 - Input channel 1 – BAT input 1;
 - Input channel 2 – BAT input 1.
5. Once the channels have been configured correctly, enter the advanced settings by pressing the last button on the right of the inverter (enter password: 0715):




6. Enter the battery settings by pressing the last button on the right of the inverter:

1. Battery parameters
2. Feed-in limit
3. IV Curve Scan
4. Logic interface
5. Factory reset
6. Parallel settings
7. Reset Bluetooth
8. CT Calibration
9. On-Off switch



7. Enter the Battery 1 item by pressing the last button on the right of the inverter:

1. Battery 1



8. Set the parameters as follows:

HYD 5000 ZSS/HYD 8000 ZSS	
BATTERY 1	
1.Battery type	WeCo
2.Battery address	00
3.Maximum charge (A)	25.00A
4.Maximum discharge (A)	25.00A
5.Depth of Discharge	80%

HYD 10000 ZSS/HYD 20000 ZSS	
BATTERY 1	
1.Battery type	WeCo
2.Battery address	00
3.Maximum charge (A)	50.00A
4.Maximum discharge (A)	50.00A
5.Depth of Discharge	80%



4.2.3.6. 5K3XP battery tower start-up

In order to carry out the correct start-up procedure:

1. The HV-BOX must be switched off;
2. The batteries must all be switched off (side switch to 0);



3. Inverter DC rotary switch set to OFF;



4. Set all batteries, via the side switch, to 1 without switching them on (**do not** press the round metal button);



5. Switch on the HV BOX via its switch;
6. The batteries will automatically switch on in succession (each module will turn on independently and the side switch will flash for 3 seconds; then a steady GREEN light will confirm that each module is powered on);
7. The HV BOX will end the start-up procedure within 90 seconds by closing the input circuit (the

RED and GREEN lights will turn on to confirm its operation);

If communication between the inverter and the HV BOX is lost for more than 60 seconds during or after the start-up phase, the HV BOX will enable the safety procedure by opening the POWER CONTACTOR. During the commissioning phase, the installer must ensure that the communication between the HV BOX and the inverter is connected properly. Do not leave the system powered when there is no communication between the HV BOX and the inverter, as prolonged standby of the system could result in an imbalance from natural self-discharge.



4.2.3.7. Installation with two 5K3XP battery towers




Figure 102 - Two battery towers

4.2.3.8. Communication between HV BOX and 5K3XP Battery Modules

The communication connections must be arranged for each tower as shown in the previous sections, using the communication cables between the battery modules:

- CAN1-B of the HV BOX to CAN-A of the first battery
- CAN-B of the first battery to CAN-A of the second battery
- ...
- CAN-B of the second-last battery to CAN-A of the last battery.

Connect all the ground masses of the batteries and HV-BOX to the ground system via appropriate terminals.

4.2.3.9. 5K3XP HV BOX – Inverter communication

In the case of two battery towers:

3. Battery Tower 1
 - a. All pins in the OFF position, except pin 1, which must be in the ON position (ADD=00000010).
4. Battery Tower 2
 - a. All pins in the OFF position, except pin 1, which must be in the ON position (ADD=10000000).

A cable from the CAN2-B input of the HV BOX of tower 1 must be connected to the CAN2-B input of the HV BOX of tower 2; finally, the Inverter/HV BOX communication cable must be inserted in the CAN2-A port of the HV BOX.




Figure 103 - Communication connections between battery towers




Figure 104 - HV BOX connection cable

The inverter and the HV BOX must be connected by populating the CAN2-A input with the Inverter-HV BOX communication cable. The other end, in which only the “orange” and “white-orange” wires are present, must be wired to the quick-connect COM connector of the hybrid inverter, as shown in the figures below.

The HV BOX must be grounded using the M5 screw terminals supplied.



Figure 105 - Inverter/HV BOX communication cable




Figure 106 - Section of inverter connections






Figure 107- "Screw-in" COM port connection




Figure 108 - "Snap-in" COM port connection



Inverter PIN	Battery communication	Notes
7	CAN H (white-orange wire)	Communication with the HV BOX of the lithium battery, the CAN of the inverter adapts to the HV BOX of the lithium battery.
8	CAN L (orange wire)	




Figure 109 - COM interface description




Figure 110 - COM connection diagram

4.2.3.10. 5K3XP power connections

The power cables in each tower between the battery modules and HV BOX must be connected as indicated in the previous section.

As for the connection between each tower and the inverter, the two power cables (+ and -) coming from the HV BOX will be connected to the two inputs of the inverter: BAT1 and BAT2.

Connect all the ground masses to the ground system using the appropriate connector.



Figure 111 - Inverter-side DC power connection with two battery inputs populated


Identify the two battery towers by assigning the number 1 to the tower connected to channel 1 and number 2 to the tower connected to channel 2.




4.2.3.11. Channel configuration (dual 5K3XP WeCo tower)

To configure the inverter channels correctly:


1. Press the first button on the left of the display:



2. Press the last arrow on the right (enter) to access the basic settings:



3. Basic settings, press the down arrow until the channel configuration item is highlighted. Now press the last arrow to the right to access the channel configuration:




4. Configure channels as described below:

Inverter channels	Inverter channel configurations
Channel 1 input	Bat input 1
	Bat input 2
	Not used
Channel 2 input (only for inverters larger than 8kW)	Bat input 1
	Bat input 2
	Not used
Channel 3 input	PV input 1
	PV input 2
	Not used
Channel 4 input	PV input 1
	PV input 2
	Not used


Set the battery inputs according to the configuration of the towers, specifically, with two 5K3XP WeCo HV BOXES connected to the inverter:

- Input channel 1 – BAT input 1;
- Input channel 2 – BAT input 2.


5. Once the channels have been configured correctly, enter the advanced settings by pressing the last button on the right of the inverter (enter password: 0715):



6. Enter the battery settings by pressing the last button on the right of the inverter:



7. Enter the Battery 1 item by pressing the last button on the right of the inverter:




8. Set the parameters as follows:

BATTERY 1	
1. Battery type	WeCo
2. Battery address	00
3. Maximum charge (A)	25.00A
4. Maximum discharge (A)	25.00A
5. Depth of Discharge	80%
6. Save	



9. Enter the Battery 2 item by pressing the last button on the right of the inverter:



10. Set the parameters as follows:

BATTERY 2	
1. Battery type	WeCo
2. Battery address	01
3. Maximum charge (A)	25.00A
4. Maximum discharge (A)	25.00A
5. Depth of Discharge	80%
6. Save	



4.2.3.12. Start-up of dual 5K3XP battery tower

In order to carry out the correct start-up procedure:

1. The HV-BOX must be switched off;
2. The batteries must all be switched off (side switch to 0);



3. Inverter DC rotary switch set to OFF;



4. Set all batteries, via the side switch, to 1 without switching them on (**do not** press the round metal button);



5. Switch on the HV BOX via its switch;
6. The batteries will automatically switch on in succession (each module will turn on independently and the side switch will flash for 3 seconds; then a steady GREEN light will confirm that each module is powered on);
7. The HV BOX will end the start-up procedure within 90 seconds by closing the input circuit (the

RED and GREEN lights will turn on to confirm its operation);

If communication between the inverter and the HV BOX is lost for more than 60 seconds during or after the start-up phase, the HV BOX will enable the safety procedure by opening the POWER CONTACTOR. During the commissioning phase, the installer must ensure that the communication between the HV BOX and the inverter is connected properly. Do not leave the system powered when there is no communication between the HV BOX and the inverter, as prolonged standby of the system could result in an imbalance from natural self-discharge.



4.2.4.5K3 and 5K3XP WeCo mixed installation

For a new system, we do not recommend installing a mixed solution with mixed 5K3 and 5K3XP batteries. When using 5K3 and 5K3XP batteries, it is mandatory to:

- Install a XP HV BOX;
- Install at least one 5K3XP battery (the XP batteries must be installed just below the XP HV BOX, while the 5k3 batteries must be inserted last).



Figure 112 - Power connection and 5K3 and 5K3XP battery communication

Communication:

The communication connections must be arranged as shown in the figure above, using the battery-to-battery communication cables, in detail:

- CAN1-B of the XP HV BOX to CAN-A of the first 5K3XP battery
- CAN-B of the first 5K3XP battery to CAN-A of the second 5K3XP battery
- ...
- CAN-B of the sixth 5K3XP battery to CAN-A of the seventh 5K3XP battery
- CAN-B of the seventh 5K3XP battery to CAN-A of the eighth 5K3 battery
- LINK-B of the seventh 5K3XP battery to LINK-A of the eighth 5K3 battery
- CAN-B of the eighth 5K3 battery to CAN-A of the ninth 5K3 battery
- LINK-B of the eighth 5K3 battery to LINK-A of the ninth 5K3 battery
- ...
- CAN-B of the second-last 5K3 battery to CAN-A of the last 5K3 battery
- LINK-B of the second-last 5K3 battery to LINK-A of the last 5K3 battery.

Connect all ground masses of the batteries and HV-BOX to the ground system via appropriate terminals.

Power:

The battery modules must be connected in series via the cables supplied.

The connector must be connected from the negative input of the first battery to the positive input of the second one. From here, the negative input must be connected to the positive input of the third module, continuing the series until the negative input of the second-last module is connected to the positive input of the last module.

In this configuration, the positive input of the first module and the negative input of the last battery will remain free (use the colour of the connector as a reference).

Subsequently, the XP HV BOX must be connected respecting the + and – polarity as it is powered by the batteries themselves. Therefore, the positive of the XP HV BOX must be connected to the positive of the first battery, and the negative of the XP HV BOX to the negative of the last battery module.

The XP HV BOX must be grounded using the M5 screw terminals supplied.

Connect all the ground masses to the ground system using the appropriate connector.

Channel configuration:

Configure the inverter channels according to the number of HV BOXES connected to the inverter (see previous paragraphs).

4.2.4.1. Start-up of mixed 5K3XP and 5K3 battery towers

In order to carry out the correct start-up procedure:

1. The HV-BOX must be switched off:
2. The batteries must all be switched off (side switch to 0);



3. Inverter DC rotary switch set to OFF;



4. Set all batteries, via the side switch, to 1 without switching them on (**do not** press the round metal button);



5. Switch on the HV BOX via its switch;
6. The batteries will automatically switch on in succession (each module will turn on independently and the side switch will flash for 3 seconds; then a steady GREEN light will confirm that each module is powered on);
7. The HV BOX will end the start-up procedure within 90 seconds by closing the input circuit (the RED and GREEN lights will turn on to confirm its operation);

If communication between the inverter and the HV BOX is lost for more than 60 seconds during or after the start-up phase, the HV BOX will enable the safety procedure by opening the POWER CONTACTOR. During the commissioning phase, the installer must ensure that the communication between the HV BOX and the inverter is connected properly. Do not leave the system powered when there is no communication between the HV BOX and the inverter, as prolonged standby of the system could result in an imbalance from natural self-discharge.



4.2.5. Installation of Azzurro HV battery

4.2.5.1. Connecting a single battery tower



Figure 113 - Single battery tower




The Azzurro HV batteries are batteries with 400VDC output, therefore, unlike the WeCo and Pylontech batteries they must not be installed in series but in parallel.
Each tower of battery modules consists of a BDU connected in parallel to multiple battery modules.

The devices to be used are:

1. The external BDU with 1 to 4 battery modules (ZZT-ZBT5K-BDU)



Figure 114 - BDU




1	Battery distribution unit	7	DC switch
2	Black START switch	8	BDU communication output (COM-OUT)
3	Battery input (BAT IN)	9	Fuse
4	BDU cascade communication port (Link)	10	Battery output (BAT Out)
5	BDU communication input (COM-IN)	11	Grounding hole
6	Grounding hole		

2. Battery modules (ZZT-BAT-ZBT5K)



Figure 115 - Battery module to be connected in parallel



1	Battery distribution unit	5	Grounding hole
2	Left-side handle	6	Communication output (Link Port Out)
3	Output terminal B+	7	Communication input (Link Port In)
4	Output terminal B-	8	Right-side handle



4.2.5.2. Communication between the BDU and Battery Modules

The communication connections must be arranged as follows, using the communication cables between battery modules:

- COM-IN of the BDU to LINK PORT IN of the first battery
- LINK PORT OUT of the first battery must be connected to LINK PORT IN of the second battery
- ...
- LINK PORT OUT of the second-last battery must be connected to LINK PORT IN of the last battery;
- The terminating resistor must be connected to LINK PORT OUT of the last battery.

Connect all the ground masses of the batteries and BDU to the ground system via appropriate terminals.



Figure 116 - Communication connections: BDU and first battery module




Figure 117 - Terminating resistor of the last battery



4.2.5.3. BDU Inverter communication




Figure 118 - Hybrid inverter and BDU communication connection

For communication between the BDU and inverter, use the black communication cable provided. The BDU side must be plugged into the COM-OUT port of the Inverter. PIN 7 (blue) and PIN 8 (white blue) COM port.




Figure 119 - PIN Out RJ45 communication cable

PIN	Wire colour	Definition	COM Port
PIN 1	White Orange		
PIN 2	Orange		
PIN 3	White Green		
PIN 4	Blue	CAN-H	PIN 7
PIN 5	White Blue	CAN-L	PIN 8
PIN 6	Green		
PIN 7	White Brown		
PIN 8	Brown		




Figure 120 - "Screw-in" COM port connection




Figure 121 - "Snap-in" COM port connection





Inverter PIN	Battery communication	Notes
7	CAN H (blue wire)	Communication with the BMS of the lithium battery, the CAN of the inverter adapts to the BMS of the lithium battery.
8	CAN L (white-blue wire)	




Figure 122 - "Screw-in" COM connection diagram




Figure 123 - "Snap-in" COM connection diagram



4.2.5.4. Power connections

The battery modules must be connected to each other in parallel via the cables shown in the figure below. The connection cables are supplied with the battery.



Figure 124 - Power connector between battery modules

The connector must be connected from the positive input of the first battery module to the positive input of the second battery, the negative input of the first module must be connected to the negative input of the second module, continuing in this way until the positive input of the second-last battery module is connected to the positive input of the last battery module and the negative input of the second-last battery module is connected to the negative input of the last battery module.

In this configuration, the positive of the first module and the negative of the first module and the positive and negative of the last battery module will remain free.




Figure 125 - Power wiring between battery modules



Subsequently, the external BDU must be connected to the first battery module. Therefore, the positive of the BDU must be connected to the positive of the first battery, and the negative of the BDU to the negative of the first battery (the cables for this connection are supplied with the BDU).



Figure 126 - Connection cables between BDU and first battery module




Figure 127 - Power connection (positive and negative) between BDU and first battery module



Finally, the BDU must be connected to the inverter via the power cables provided, as shown in the figure.



Figure 128 - BDU Inverter power cables




Figure 129 - BMS power connection




Figure 130 - Inverter-side DC power connection with a single battery input populated

4.2.5.5. Channel configuration (single Azzurro tower)

To configure the inverter channels correctly:


1. Press the first button on the left of the display:



2. Press the last arrow on the right (enter) to access the basic settings:

1. Basic settings
2. Advanced settings
3. Production statistics
4. System Info
5. Event list
6. SW Update

3. Basic settings, press the down arrow until the channel configuration item is highlighted. Now press the last arrow to the right to access the channel configuration:

1. Language
2. Date and Time
3. Safety parameters
4. Working mode
5. Self-Test
6. Channel configuration
7. EPS Mode
8. Communication address



4. Configure channels as described below:

Inverter channels	Inverter channel configurations
Channel 1 input	Bat input 1
	Bat input 2
	Not used
Channel 2 input (only for inverters larger than 8kW)	Bat input 1
	Bat input 2
	Not used
Channel 3 input	PV input 1
	PV input 2
	Not used
Channel 4 input	PV input 1
	PV input 2
	Not used

Set the battery inputs according to the configuration of the towers, specifically, with only one Pylontech BMS connected to the inverter:

- Input channel 1 – BAT input 1;
- Input channel 2 – Not used.


5. Once the channels have been configured correctly, enter the advanced settings by pressing the last button on the right of the inverter (enter password: 0715):

1. Basic settings
2. Advanced settings
3. Production statistics
4. System Info
5. Event list
6. SW Update





6. Enter the battery settings by pressing the last button on the right of the inverter:

1. Battery parameters
2. Feed-in limit
3. IV Curve Scan
4. Logic interface
5. Factory reset
6. Parallel settings
7. Reset Bluetooth
8. CT Calibration
9. On-Off switch



7. Enter the Battery 1 item by pressing the last button on the right of the inverter:

1. Battery 1




8. Set the parameters as follows:


BATTERY 1	
1.Battery type	HV ZBT
5.Depth of Discharge	80%
6.Save	



9. Access the Automatic Addr. cfg item by pressing the last button on the right of the inverter:



3. The total number of batteries in the tower will appear



4. The configuration will take about 30 seconds, after which the OK message appears.



4.2.5.6. Installation of dual battery tower



Figure 131 - Dual battery tower



4.2.5.7. Communication between the BDU and Battery Modules

The communication connections must be arranged as follows, using the communication cables between battery modules:

- COM-IN of the BDU to LINK PORT IN of the first battery
- LINK PORT OUT of the first battery must be connected to LINK PORT IN of the second battery
- ...
- LINK PORT OUT of the second-last battery must be connected to LINK PORT IN of the last battery;
- The terminating resistor must be connected to LINK PORT OUT of the last battery.

Connect all battery and BDU grounds to the ground system via appropriate terminals.



Figure 132 - Communication connections: BDU and first battery module




Figure 133 - Terminating resistor of the last battery



4.2.5.8. Communication between BDU 1 and BDU 2



Figure 134 – Communication cable between BDU1 and BDU2

Connect the two BDUs from COM-OUT BDU1 to LINK BDU2, as shown in the figure below.
The inverter must be connected from BDU2 via the COM-OUT port.




Figure 135 – Communication connections between the Azzurro towers



4.2.5.9. BDU2 Inverter communication




Figure 136 -Hybrid inverter and BDU communication connection

For communication between the BDU and inverter, use the black communication cable provided. The BDU side must be plugged into the COM-OUT port of the Inverter. PIN 7 (blue) and PIN 8 (white blue) COM port.




Figure 137 - PIN Out RJ45 communication cable

PIN	Wire colour	Definition	COM Port
PIN 1	White Orange		
PIN 2	Orange		
PIN 3	White Green		
PIN 4	Blue	CAN-H	PIN 7
PIN 5	White Blue	CAN-L	PIN 8
PIN 6	Green		
PIN 7	White Brown		
PIN 8	Brown		




Figure 138 - "Screw-in" COM port connection




Figure 139 - "Snap-in" COM port connection





Inverter PIN	Battery communication	Notes
7	CAN H (blue wire)	Communication with the BMS of the lithium battery, the CAN of the inverter adapts to the BMS of the lithium battery.
8	CAN L (white-blue wire)	




Figure 140 - "Screw-in" COM connection diagram




Figure 141 - "Snap-in" COM connection diagram



4.2.5.10. Power connections

The battery modules must be connected to each other in parallel via the cables shown in the figure below. The connection cables are supplied with the battery.



Figure 142 - Power connector between battery modules

The connector must be connected from the positive input of the first battery module to the positive input of the second battery, the negative input of the first module must be connected to the negative input of the second module, continuing in this way until the positive input of the second-last battery module is connected to the positive input of the last battery module and the negative input of the second-last battery module is connected to the negative input of the last battery module.

In this configuration, the positive of the first module and the negative of the first module and the positive and negative of the last battery module will remain free.




Figure 143 - Power wiring between battery modules



Subsequently, the external BDU must be connected to the first battery module. Therefore, the positive of the BDU must be connected to the positive of the first battery, and the negative of the BDU to the negative of the first battery (the cables for this connection are supplied with the BDU).



Figure 144 - Connection cables between BDU and first battery module




Figure 145 - Power connection (positive and negative) between BDU and first battery module



Finally, the BDU must be connected to the inverter via the power cables provided, as shown in the figure.



Figure 146 - BDU Inverter power cables




Figure 147 - BMS power connection

As for the connection between each tower and the inverter, the two power cables (+ and -) coming from each BDU will be connected to the two inputs of the inverter: BAT1 and BAT2. Identify the two battery towers by assigning the number 1 to the tower connected to channel 1 and number 2 to the tower connected to channel 2.



Figure 148 - Inverter-side DC power connection with two battery inputs populated




4.2.5.11. Channel configuration (dual Azzurro tower)

To configure the inverter channels correctly:


1. Press the first button on the left of the display:



2. Press the last arrow on the right (enter) to access the basic settings:



3. Basic settings, press the down arrow until the channel configuration item is highlighted. Now press the last arrow to the right to access the channel configuration:




4. Configure channels as described below:

Inverter channels	Inverter channel configurations
Channel 1 input	Bat input 1
	Bat input 2
	Not used
Channel 2 input (only for inverters larger than 8kW)	Bat input 1
	Bat input 2
	Not used
Channel 3 input	PV input 1
	PV input 2
	Not used
Channel 4 input	PV input 1
	PV input 2
	Not used


Set the battery inputs according to the configuration of the towers, specifically, with two Pylontech Battery Management Systems connected to the inverter:

- Input channel 1 – BAT input 1;
- Input channel 2 – BAT input 2.


5. Once the channels have been configured correctly, enter the advanced settings by pressing the last button on the right of the inverter (enter password: 0715):



6. Enter the battery settings by pressing the last button on the right of the inverter:




7. Enter the Battery 1 item by pressing the last button on the right of the inverter:



5. Set the parameters as follows:

BATTERY 1	
1.Battery type	HV ZBT
5.Depth of Discharge	80%
6.Save	


8. Enter the Battery 2 item by pressing the last button on the right of the inverter:




6. Set the parameters as follows:

BATTERY 2	
1.Battery type	HV ZBT
5.Depth of Discharge	80%
6.Save	

7. Access the Automatic. Addr. cfg item by pressing the last button on the right of the inverter:

1. Battery 1
2. Battery 2
3. Automatic addr. cfg


8. The total number of batteries in the tower will appear

HV ZBT Automatic Address
Number of batteries
X


9. The configuration will take about 30 seconds, after which the OK message appears.



4.2.2. Installing Azzurro HV Smart 5K batteries

8.2.1.1. Connecting a single battery tower



Figure 149 - Single battery tower



The Azzurro HV Smart 5K batteries are batteries with output at 400VDC, therefore, unlike the Weco and Pylontech batteries must not be installed in series but in parallel.
Each battery module tower is composed of a BDU connected to the parallel of several battery modules.

The devices to be used are:

1. The external BDU from 1 to 8 battery modules (ZZT-AHV5K-BDU)





Figure 150 – BDU Smart 5K

Symbol	Component	Symbol	Component
1	Start button	6	Grounding point
2	Antenna	7	Communication port of the inverter
3	Communication port: COM output	8	Communication port: COM entry
4	Port for debugging	9	DC switch
5	Power terminals: +/-	10	System indicator panel

2. Battery modules (ZZT-BAT-AHV5K)



Figure 151 –Module to be connected in parallel



Symbol	Component	Symbol	Component
(1)	Lower connector	(5)	radiator
(2)	Positioning pin	(6)	Battery module Indicator panel
(3)	of switching	(7)	Top connector
(4)	Mounting hole for battery module		



8.2.1.2. Communication between BDU Smart 5K and Smart 5K Battery Modules

Secure the grounding cable to the BDU grounding hole with M5 screws and secure the other end of the cable to the on-site grounding bus with a torque of 3 Nm.




Figure 152 - Connection of grounding cable

The battery tower requires no cables to connect batteries together and to the BDU Smart 5K, both for power and communication

The batteries must be stacked one on top of the other, and the connections are plug & play.



Figure 153 - Plug&play connection




Figure 154 - Communication and power connections between battery modules



8.2.1.3. BDU Smart 5K and Inverter communication




Figure 155 - Hybrid inverter and BDU Smart 5K communication connection




Figure 156 - Pin Out CAN RJ45 communication cable

PIN	Colour of the wire	Definition	COM port
PIN 1	White Orange		
PIN 2	Orange		
PIN 3	White Green		
PIN 4	Blue	CAN-H	PIN 7
PIN 5	White Blue	CAN-L	PIN 8
PIN 6	Green		
PIN 7	White Brown		
PIN 8	Brown		




Figure 157 - "Screw-in" COM port connection




Figure 158 - "Snap-in" COM port connection





Inverter PIN	Battery communication	Notes
7	CAN H (blue wire)	Communication with the BMS of the lithium battery, the CAN of the inverter adapts to the BMS of the lithium battery.
8	CAN L (white-blue wire)	




Figure 159 - "Screw-in" COM connection diagram




Figure 160 - "Snap-in" COM connection diagram



8.2.1.4. Power connections

The battery tower requires no cables to connect batteries together and to the BDU Smart 5K, both for power and communication

The batteries must be stacked one on top of the other, and the connections are plug & play.



Figure 161 – Plug&play connection




Figure 162 - Communication and power connections between battery modules

Finally, the BDU Smart 5K must be connected to the inverter through the power cables provided.

As for the power connections between the BDU and the inverter, it is possible to connect both channels coming from the inverter through special Y-connectors (if properly set, the battery column can manage the maximum power of the inverter, both in charge and discharge).

For Y-DC connectors, choose a model that can support at least 35A for the male and female connector and at least 70A in the branch body.

Before installing/choosing the correct Y-connector, check with the Zucchetti Centro Sistemi Spa pre-sales department.

CASE 1: Connection BDU Smart 5K to 1 channel Inverter:




Figure 163 - Power connection BDU Smart 5K



Figure 164 - Inverter-side DC power connection with a single battery input populated

CASE 2: Connection BDU Smart 5K to both channels Inverter:

For Y-DC connectors, choose a model that can support at least 35A for the male and female connector and at least 70A in the branch body.

Before installing/choosing the correct Y-connector, check with the Zucchetti Centro Sistemi Spa pre-sales department.



Figure 165 - Y-Type Connection Cable




Figure 166 - Connessione potenza BDU Smart 5K




Figure 167 - Inverter side DC power connection with two battery-loaded inputs


8.2.1.5. Channel configuration (single Azzurro Smart 5K tower)

To configure the inverter channels correctly:


1. Press the first button on the left of the display:



2. Press the last arrow on the right (enter) to access the basic settings:



3. Basic settings, press the down arrow until the channel configuration item is highlighted. Now press the last arrow to the right to access the channel configuration:



4. Configure channels as described below:



Inverter channels	Inverter channel configurations
Channel 1 input	Bat input 1
	Bat input 2
	Not used
Channel 2 input (only for inverters larger than 8kW)	Bat input 1
	Bat input 2
	Not used
Channel 3 input	PV input 1
	PV input 2
	Not used
Channel 4 input	PV input 1
	PV input 2
	Not used

Set the battery inputs according to the configuration of the towers, specifically, with only one BDU Smart 5K connected to the inverter:


For HYD 5000 ZSS/HYD 8000 ZSS inverters (single battery input):

- Input channel 1 – BAT input 1;
- Input channel 2 – Not used.


For HYD 10000 ZSS/HYD 20000 ZSS inverters (single battery input):

- Input channel 1 – BAT input 1;
- Input channel 2 – BAT input 1.


5. Once the channels have been correctly configured, enter the advanced settings by pressing the last button on the right of the inverter (enter password: 0715):



6. Enter the battery settings by pressing the last button on the right of the inverter:



7. Enter the Battery 1 item by pressing the last button on the right of the inverter:



8. Set the parameters as follows:


BATTERY 1	
1.Battery type	Pylon
2.Battery address	01
3.Maximum charge (A)	25.00A
4.Maximum discharge (A)	25.00A
5.Depth of Discharge	80%
6.Save	



8.2.1.6. Azzurro HV Smart 5K5 battery tower start-up

In order to perform the correct ignition procedure:

1. Close the side switch of the BDU Smart 5K;



2. Press the START metal switch (about 3~6s) of the BDU Smart 5K to start it, the LED lights will light up in succession;





8.2.1.7. Installation with two battery towers



Figure 168 - Two battery towers



8.2.1.8. Communication between the BMS (SC500 and SC1000) and Battery Modules

Secure the grounding cable to the BDU grounding hole with M5 screws and secure the other end of the cable to the on-site grounding bus with a torque of 3 Nm.




Figure 169 - Connection of grounding cable

The battery tower requires no cables to connect batteries together and to the BDU Smart 5K, both for power and communication

The batteries must be stacked one on top of the other, and the connections are plug & play.



Figure 170 - Plug&play connection




Figure 171 - Communication and power connections between battery modules



8.2.1.9. Comunicazione fra BDU Smart 5K 1 e BDU Smart 5K 2



Figure 172 – Communication cable between BDU Smart 5K 1 and BDU

Connect the two BDUs from COM-OUT BDU1 to COM IN BDU2 as shown in the figure below.
 The inverter must be connected from BDU1 via the PCS port.




Figure 173 – Communication connections between the Blue towers



8.2.1.10. BDU Smart 5K and Inverter communication




Figure 174 - Hybrid inverter and BDU Smart 5K communication connection




Figure 175 - Pin Out CAN RJ45 communication cable

PIN	Colour of the wire	Definition	COM port
PIN 1	White Orange		
PIN 2	Orange		
PIN 3	White Green		
PIN 4	Blue	CAN-H	PIN 7
PIN 5	White Blue	CAN-L	PIN 8
PIN 6	Green		
PIN 7	White Brown		
PIN 8	Brown		




Figure 176 - "Screw-in" COM port connection




Figure 177 - "Snap-in" COM port connection





Inverter PIN	Battery communication	Notes
7	CAN H (blue wire)	Communication with the BMS of the lithium battery, the CAN of the inverter adapts to the BMS of the lithium battery.
8	CAN L (white-blue wire)	




Figure 178 - "Screw-in" COM connection diagram




Figure 179 - "Snap-in" COM connection diagram

8.2.1.11. Power connections

The battery tower requires no cables to connect batteries together and to the BDU Smart 5K, both for power and communication

The batteries must be stacked one on top of the other, and the connections are plug & play.



Figure 180 - Plug&play connection




Figure 181 - Communication and power connections between battery modules



Finally, the BDU Smart 5K must be connected to the inverter through the power cables provided.




Figure 182 - Power connection BDU Smart 5K

As for the connection between each tower and the inverter, from each BDU Smart 5K will start two power cables (+ and -) that must be connected to the two inputs of the inverter: BAT1 and BAT2
Identify the two battery towers by assigning number 1 to the tower connected to channel 1 and number 2 to the tower connected to channel 2.



Figure 183 - Power connection DC inverter side with double battery input populated


8.2.1.12. Channel configuration of Smart 5K dual tower

To configure the inverter channels correctly:


1. Press the first button on the left of the display:



2. Press the last arrow on the right (enter) to access the basic settings:



3. Basic settings, press the down arrow until the channel configuration item is highlighted. Now press the last arrow to the right to access the channel configuration:



4. Configure channels as described below:




Inverter channels	Inverter channel configurations
Channel 1 input	Bat input 1
	Bat input 2
	Not used
Channel 2 input (only for inverters larger than 8kW)	Bat input 1
	Bat input 2
	Not used
Channel 3 input	PV input 1
	PV input 2
	Not used
Channel 4 input	PV input 1
	PV input 2
	Not used


Set the battery inputs according to the configuration of the towers, specifically, with two BDU Smart 5K Battery Management Systems connected to the inverter:

- Input channel 1 – BAT input 1;
- Input channel 2 – BAT input 2.

5. Once the channels have been configured correctly, enter the advanced settings by pressing the last button on the right of the inverter (enter password: 0715):




6. Enter the battery settings by pressing the last button on the right of the inverter:



7. Enter the Battery 1 item by pressing the last button on the right of the inverter:




1. Battery 1
2. Battery 2


8. Set the parameters as follows:

BATTERY 1	
1. Battery type	Pylon
2. Battery address	01
3. Maximum charge (A)	25.00A
4. Maximum discharge (A)	25.00A
5. Depth of Discharge	80%
6. Save	

9. Enter the Battery 2 item by pressing the last button on the right of the inverter:

3. Battery 1
4. Battery 2




10. Set the parameters as follows:

BATTERY 2	
1.Battery type	Pylon
2.Battery address	02
3.Maximum charge (A)	25.00A
4.Maximum discharge (A)	25.00A
5.Depth of Discharge	80%
6.Save	

8.2.1.13. Azzurro HV Smart 5K5 battery tower start-up

In order to perform the correct ignition procedure:

1. Close the side switch of the BDU Smart 5K;



2. Press the START metal switch (about 3~6s) of the BDU Smart 5K to start it, the LED lights will light up in succession;





2. External communication

2.1. USB/Wi-Fi




Figure 184 - External Wi-Fi connection

PIN	Definition	Function	Notes
1	GND.S	Power Supply - USB	The USB power supply is 5V/1A; It cannot be used to charge external devices
2	DP	Data + USB	
3	DM	Data - USB	
4	VBUS	Power Supply - USB	

Table 7 - Interface description

2.2. DRMs Interface - Logical Interface

Procedure:

- 1) Position the wire terminals according to the colour sequence shown in Figure185.




Figure185 – Connecting the DRMs interface (1)




Figure 186 – Connecting the DRMs interface (2)

- 2) Pass the cable terminal through the cable gland, insert the communication cable into the RJ45 connector. The pins of the logical interface are defined according to the different standard requirements:
 - a) Logical interface according to the VDE-AR-N 4105 standard: 2018-11, necessary for controlling and/or limiting the output power of the inverter. The inverter can be connected to a RRCR (Radio Control Receiver), together with all the other inverters in the installation, so as to dynamically limit the output power.

- b) Logical interface in accordance with the EN50549-1:2019 standard, necessary for interrupting the output power supply within 5 seconds following an instruction received from the interface.




Figure 187 - RRCR connection

Pin	Name	Description	Connected to (RRCR)
1	L1	Input contact relay 1	K1 – Output relay 1
2	L2	Input contact relay 2	K2 – Output relay 2
3	L3	Input contact relay 3	K3 – Output relay 3
4	L4	Input contact relay 4	K4 – Output relay 4
5	NC	Not connected	Not connected
6	G	GND	Relay common node
7	NC	Not connected	Not connected
8	NC	Not connected	Not connected

L1	L2	L3	L4	Active power	Cos(φ)
1	0	0	0	0%	1
0	1	0	0	30%	1
0	0	1	0	60%	1

0	0	0	1	100%	1
---	---	---	---	------	---

Table 8 - Terminal description

Table 9 - Inverter preconfigured for the RRCR power levels (1 closed, 0 open)

No.	PIN name	Description	Connected to (RRCR)
1	L1	Input contact relay 1	K1 - Output relay 1
2	NC	Not connected	Not connected
3	NC	Not connected	Not connected
4	NC	Not connected	Not connected
5	NC	Not connected	Not connected
6	G	GND	K1 - Output relay 1
7	NC	Not connected	Not connected
8	NC	Not connected	Not connected

Table 10- Terminal description

L1	Active Power	Power drop rate	Cos(φ)
1	0%	< 5 seconds	1
0	100%	/	1

Table 11 - Inverter preconfigured for the RRCR power levels (1 closed, 0 open)



2.3. COM communication - Multifunction




Figure 188 - COM interface

Refer to the figure below for the RS485 connection, if you want “cascade” monitoring of the inverters.




Figure 189 - RS485 connection (monitoring between inverters)

PIN	Definition	Function	Notes
1	RS485A1-1	RS485 differential signal +	Wired or cascade monitoring of the inverter
2	RS485A1-2	RS485 differential signal +	
3	RS485B1-1	RS485 differential signal -	
4	RS485B1-2	RS485 differential signal -	
5	RS485A2	RS485 differential signal +	Communication with three-phase meters
6	RS485B2	RS485 differential signal -	
7	CAN0_H	CAN positive polarity	Communication with BMS of the lithium battery
8	CAN0_L	CAN negative polarity	
9	GND.S	GND communication BMS	
10	485TX0+	RS485 differential signal +	
11	485TX0-	RS485 differential signal -	
12	GND.S	GND signal	Lead-acid battery temperature measurement
13	BAT Temp	Lead-acid battery temperature probe	
14	DCT1	Dry Contact1	Option of the electric switch function
15	DCT2	Dry Contact2	
16	VCC	VCC communication	12V power supply

Table 12 - Interface description





2.4. Measurement of currents exchanged with the grid

Measurement of the currents exchanged with the grid is fundamental for the correct functioning of the energy storage in the battery.

There are two ways to take this measurement correctly:

1. Direct use of CT sensors (ZST-ACC-TA model).
2. Use of meter and CT sensors. In this case, both the current probes offered by ZCS and other types of probes can be connected to the meter, which must be correctly set on the meter.

The first method can be applied in all cases where the distance between the hybrid inverter and the sensor insertion point is less than 50 meters. To extend the + and – cables of the CT, use a Category-6 8-pin STP cable and connect the shield to the ground on one of the two sides.

If the distance is greater than 50 meters, then the second method must be used.

The correct insertion point of the sensors or the Meter + CT sensors for measuring the currents exchanged with the grid is shown in the figure below.

2.4.1. Direct connection of CT sensors

In the case of direct connection of the CT sensors, use the dedicated connections supplied with the inverter as shown in the figure.

These sensors must be connected directly to the CT input of the inverter shown in the figure, according to the indications in the table.




Figure 190 - Numbered connections of the CT connector

PIN	Definition	Function	Notes
1	Ict_R-	Negative R-phase sensor (L1)	Used to connect the R-phase current sensor (L1)
2	Ict_R+	Positive R-phase sensor (L1)	
3	Ict_S-	Negative S-phase sensor (L2)	Used to connect the S-phase current sensor (L2)
4	Ict_S+	Positive S-phase sensor (L2)	
5	Ict_T-	Negative T-phase sensor (L3)	Used to connect the T-phase current sensor (L3)
6	Ict_T+	Positive T-phase sensor (L3)	

Table 13 - Interface Description




Figure 191 - CT Interface

Take care to correctly identify the three phases as they are connected to the inverter on the grid connector. The sensors of each phase must match.
Position the sensors according to the direction on the sensor (arrow).

P1 → P2 Grid




Figure 192 - Reference to sensor direction

If it is necessary to extend the sensor connection cables, use STP network cables and connect the shield to the ground on one of the two sides.
This cable can be extended only up to a maximum of 50 metres, otherwise a meter must be used.
Make sure to properly insulate the extension connections so as to prevent any problems with low insulation and/or COM port failure.






Figure 193 - Installation diagram of hybrid three-phase inverter with CT



2.4.2. Connecting the Meter

Due to the stability of the RS485 signal, for distances greater than 50 meters between the inverter and measuring point, it is necessary to use the Meter in addition to the sensors, as shown in the figure.

Make sure to position the probes so that each toroid reads only the current flows relating to the exchange. To do this, it is recommended to position them at the output of the exchange meter.




Figure 194 - Installation diagram of hybrid inverter with Meter on the exchange

This involves connecting the sensors to the Meter, and then connecting the Meter to the inverter via a serial port.

The sensors connected to the Meter must **never** be extended (use the cables supplied).




Figure 195 - Meter (left), CT sensors (right)

Connect the Meter and sensors according to the diagram shown in the figure below.
Connect PIN 10 of the Meter to the neutral wire (N), connect PINs 2, 5 and 8 to phases R, S and T respectively.

As regards the connections with the CT sensors, the terminals of the R-phase sensor must be connected to PIN 1 (red wire) and PIN 3 (black wire).

The terminals of the S-phase sensor must be connected to PIN 4 (red wire) and PIN 6 (black wire).

The terminals of the T-phase sensor must be connected to PIN 7 (red wire) and PIN 9 (black wire).
Position the sensors according to the direction on the sensor (arrow).

ATTENTION: attach the CT sensors to the phases only after they have been connected to the Meter.




Figure 196 - Meter and sensor connections

Connect the Meter and inverter via the RS485 serial port.

On the Meter side, this port is identified by PINs 24 and 25.

On the inverter side, use the connection port identified as "COM" by connecting PINs 5 and 6 as shown in the figures and tables below.




Figure 197 – “Screw-in” COM interface




Figure 198 – “Snap-in” COM interface



Inverter PIN	Definition	PIN Meter	Notes
5	RS485 differential signal +	24	Communication with Meters
6	RS485 differential signal -	25	

Table 14 - Interface description




Figure 199 - Connection of "screw-in" Meter serial port




Figure 200 - Connection of "snap-in" Meter serial port

NOTE: For distances greater than 100 meters between the Meter and hybrid inverter it is recommended to connect two 120 Ohm resistors along the 485 daisy chain: the first to the inverter (between PINs 5 and 6 of the interface), and the second directly to the Meter (PINs 24 and 25).

2.4.3. Measuring the photovoltaic production

If one or more photovoltaic inverters are already in the system, the hybrid system must not only show the photovoltaic contribution of the panels connected to its inputs, but also the power produced by external photovoltaic panels, in order to make the storage system work properly. All this must be achieved by connecting a second Meter (or up to a maximum of 3 to read an external production) in a suitable position that allows reading the entire production of the pure photovoltaic system (excluding that of the hybrid three-phase inverter). As for the RS485 communication (Meter - HYD), all the Meters present must be connected to the COM port of the inverter in inputs 5 and 6 of the interface.




Figure 201 - Installation diagram of Hybrid inverter with Meter on exchange and production




Figure 202 - Connection of "screw-in" COM serial port with more than one Meter






Figure 203 - Connection of “snap-in” COM serial port with more than one Meter

2.4.3.1. Configuring the Meter parameters

After connecting the cables correctly, it is necessary to set the correct parameters from the Meter display.



1. Press to:
 - “Confirm”
 - “Move cursor”
 (to enter digit)
2. Press to “go back”
3. Press to “add”

Figure 204 - Meter Legend

Exchange Meter configuration

To configure the device in read mode on the **exchange**, enter the settings menu as shown below:

1. Press **SET** and the word **CODE** will appear



2. Press **SET** again and “600” will appear:



3. Enter the number “701”:

- a. From the first screen where the number “600” appears, press the “→” key once to write the number “601”.
- b. Press “**SET**” twice to move the cursor left, highlighting “601”;
- c. Press the “→” key several times until the number “701” is written (701 is the code for accessing the settings).

Note: In case of error, press “ESC” and then “SET” again to reset the required code.



4. Confirm by pressing **SET** until you enter the settings menu.

5. Enter the following menus and set the parameters indicated:

a. **CT:**

- i. Press **SET** to enter the menu
- ii. Write “40”:

 1. From the first screen where the number “1” appears, press the “→” key several times until the number “10” is written.
 2. Press “**SET**” once to move the cursor left, highlighting “10”
 3. Press the “→” key several times until the number “40” is written

Note: In case of error, press “SET” until the digit for thousands is highlighted and then press “→” until only the number “1” appears; at this point repeat the procedure described above.



iii. Press “ESC” to confirm and “→” to scroll to the next setting.

b. **ADDRESS:**

- i. Leave address 01 (default setting) so that the inverter assigns the data sent by the meter as the power relating to the exchange.

Configuring Meter on exchange and production

To configure the device in read mode on the **exchange**, refer to the instructions in the previous section (Configuring Meter on exchange).

To configure the device in read mode on **production**, enter the settings menu, as shown below:

1. Press **SET** and the word **CODE** will appear



2. Press **SET** again and “600” will appear:



3. Enter the number “701”:
 - a. From the first screen where the number “600” appears, press the “→” key once to write the number “601”.
 - b. Press “**SET**” twice to move the cursor left, highlighting “601”;
 - c. Press the “→” key several times until the number “701” is written (701 is the code for accessing the settings).

Note: In case of error, press “ESC” and then “SET” again to reset the required code.



4. Confirm by pressing **SET** until you enter the settings menu.
5. Enter into the following menus and set the parameters indicated:
 - a. **CT:**
 - i. Press **SET** to enter the menu
 - ii. Write “40”:

1. From the first screen where the number “1” appears, press the “→” key several times until the number “10” is written.
2. Press “SET” once to move the cursor left, highlighting “10”
3. Press the “→” key several times until the number “40” is written

Note: In case of error, press “SET” until the digit for thousands is highlighted and then press “→” until only the number “1” appears; at this point repeat the procedure described above.



- iii. Press “ESC” to confirm and “→” to scroll to the next setting.

b. ADDRESS:

- i. Press **SET** to enter the menu:
- ii. Write “02” (by pressing “→” once from screen “01”). With address 02, the inverter assigns the data sent by the meter as production power. A maximum of 3 meters can be set for the production (Addresses 02, 03 and 04).



- iii. Press “ESC” to confirm.

2.4.3.2. Checking the correct installation of the Meter


Check the Meter on Exchange

To carry out this check, it is necessary to:


- Switch on only the hybrid inverter in alternating mode and switch off any other source of photovoltaic production (if present);
- Switch on loads of more than 1 kW for each of the three phases of the system;

Stand in front of the Meter and use the “→” keys to scroll through the items, and “ESC” to go back, checking that:


1. The Power Factor values for each phase Fa, Fb and Fc (phase shift between voltage and current) are between 0.8-1.0. If the value is lower, move the sensor to one of the other two phases until the value is between 0.8-1.0.



2. The Pa, Pb and Pc Powers are:
- Greater than 1 kW.
 - In line with the home consumption.
 - The sign in front of each negative value (-).



3. Switch on the photovoltaic system of the inverter by turning the switch to ON and the batteries, check that the total power value (Pt) is in line with the value shown on the inverter's display.



Checking the Meter on Production

In case of **meter on production**, repeat the above steps:

1. Switch off the hybrid inverter and only leave the pure photovoltaic system on;
2. Operate the pure photovoltaic system in production mode;
3. Check the Power Factor as described in the previous case;
4. The sign of the Pa, Pb, and Pc powers must match;
5. Switch on the Hybrid Inverter, check that the total PV power value (Pt) is in line with the value shown on the inverter's display.

2.5. Inverter Mode in parallel

If there is more than one hybrid inverter in a system, they must be connected in parallel (Master-Slave mode).

For maximum performance of the system and to have future imbalances between the towers, the hybrid inverters must be the same as each other (i.e. same size, number and models of batteries). This mode makes it possible to synchronise the charging and discharging power of multiple interconnected hybrid inverters in order to maximise self-consumption.




Figure 205 - Single-line diagram of parallel inverter connection

2.5.1. Connections between inverters

- The inverters must be interconnected using the cable supplied, making sure to populate the inputs as follows:
 - Link port 1 of Master Inverter → Link port 0 of Slave 1 Inverter
 - Link port 1 of Slave 1 Inverter → Link port 0 of Slave 2 Inverter
 - Link port 1 of Slave 2 Inverter → Link port 0 of Slave 3 Inverter
 - ...
 - Link port 1 of Slave n-1 Inverter → Link port 0 of Slave n Inverter

NOTE: the inverter parallel cable supplied is 3 meters long and cannot be extended.

- If the inverters connected are of the same size, the LOAD outputs can be connected in parallel in order to supply power to the same group of priority loads. To do this, a parallel switchboard must be used and all hybrid inverters must be equipped with batteries (if even one inverter in the parallel setup lacks a battery, the EPS cannot be enabled). Make sure that the connections between each inverter and the parallel switchboard have the same length and cross-section, and have the lowest possible impedance. It is recommended to install suitable protection on each connection line between the inverter and switchboard.
- The total load connected to the LOAD outputs must be less than the total sum of the power outputs of the inverters in EPS mode.




Figure 206 - Parallel connections between inverters

PIN	Definition	Function	Notes
1	IN_SYN0	Signal synchronisation 0	The high signal level is 12 V
2	CANL	CAN negative polarity	
3	SYN_GND0	Signal synchronisation GND0	
4	CANH	CAN positive polarity	
5	IN_SYN1	Signal synchronisation 1	
6	SYN_GND1	Signal synchronisation GND1	
7	SYN_GND2	Signal synchronisation GND2	
8	IN_SYN2	Signal synchronisation 2	

Table 15 - Interface description

3. Buttons and indicator lights




Figure 207 – Screen

The buttons on the screen have the following functions:

- “Back” - to go back to the previous screen or enter the main page;
- “Up” - to move up the menu or for the +1 function;
- “Down” - to move down the menu or for the -1 function;
- “OK” - to select the current option of the menu, or to move.

Status	Connected to the grid Green light	Off-Grid Green light	Alarm Red light
Connected to the grid	ON		
Standby (connected to the grid)	Flashing		
Off-Grid		ON	
Standby (Off-Grid)		Flashing	
Alarm			ON

Table 16 - Meaning of lights



4. Operation

Check the following points and make sure the connections have been made before starting the inverter.

1. The inverter must be securely fixed to the wall bracket.
2. The PV+/PV- wires are securely connected with the correct polarity and voltage.
3. The BAT+/BAT- wires are securely connected with the correct polarity and voltage.
4. The GRID/LOAD cables are connected securely/correctly.
5. The AC switch is correctly connected between the inverter's GRID port and the GRID, with the automatic switch: OFF.
6. The AC switch is correctly connected between the inverter's LOAD port and the critical load, with the automatic switch: OFF.
7. The communication cable of the lithium battery must be correctly connected.

3.1. Before configuration (follow carefully)

IMPORTANT: Carefully follow the procedure to activate the inverter


1. Ensure that there is no power generation on the phases of the inverter
2. Turn on the batteries:
 - a. Pylontech Battery
 - i. Set the DC switch of the inverter to ON
 - ii. Set the Power Switch (DC disconnect switch) on the front of the BMS to ON
 - iii. Press the red START button of the BMS for one second
 - b. WeCo batteries
 - i. Arm the GENERAL BREAKER present on the front of HV BOX.
 - ii. Once the HV BOX has closed the contactor, set the Inverter DC switch to ON.
 - c. Azzurro Battery
 - i. Arm the rotary switch on the BDU
 - ii. Set the DC switch of the inverter to ON
3. Set the AC differential switch between the inverter's GRID input and the grid to ON
4. Set the AC differential switch between the inverter's LOAD input and the critical load to ON
5. The inverter should turn on and start running (if all steps have been performed correctly)

3.2. Commissioning

Before starting the actual operation of the inverter, some parameters will need to be set, as shown in the table below.

Parameters	Notes
1. OSD language options	Default English
2. Setting of date and time, confirmation	If the inverter is connected to a PC or mobile app, the time should be set to the local time
*3. Importing of safety parameters	Find the file with the safety parameters (renamed according to the country selected) on the website, download them to a USB stick and import them
4. Setting the input channels	Default order: BAT1, BAT2, PV1, PV2
*5. Setting battery parameters	Default values are shown according to the input channel configured
6. Set-up is complete	

Table 17 - Parameters to be set for first start-up

	<p>It is very important to make sure that the right country code has been selected in accordance with the requirements of the local energy authorities.</p> <p>Consult with qualified and authorised personnel to ensure the correct choice</p>
Caution	

NB: Zucchetti Centro Sistemi S.p.A. shall not be held responsible for any harmful consequences resulting from the incorrect setting of the country code.



3.2.1.OSD language options

1.中文
2.English
3.Italian
4.
.....

OK

3.2.2.Setting of date and time, confirmation

Time
YYYY-MM-DD hh:mm:ss

3.2.3.Importing of safety parameters

The user can modify the safety parameters of the machine via a USB stick, and must copy and modify the values on the USB stick beforehand. To enable this option, contact Zucchetti Centro Sistemi S.p.A.





Code	Region		Code	Region					
000	000	Germany	VDE4105	018	EU	EN50438			
	001		VDE4110			001	EN50549		
	002		VDE0126			002	EU-EN50549-HV		
	003		VDE4105-HV	020	Korea	Korea			
	004		BDEW-HV			001	Korea-DASS		
001	000	Italy	CEI-021 Internal	021	Sweden				
	001		CEI-016 Italy			000	EU General		
	002		CEI-021 External	022	Europe General	EU General-MV			
	003		CEI-021 In Areti			001	EU General-HV		
	004		CEI-021In--HV	025	India	Cyprus			
						000	India		
		001	India-MV						
002	000	Australia	Australia	026	Philippines	India-HV			
	008		Australia-B			000	PHI		
	009		Australia-C			001	PHI-MV		
003	000	Spain	ESP-RD1699	027	New Zealand	New Zealand			
	001		RD1699-HV			001	New Zealand-MV		
	002		NTS			002	New Zealand-HV		
	003		UNE217002+RD647	028	Brazil	Brazil			
	004		Spian Island			000	Brazil-LV		
004	000	Turkey	Turkey	002	Brazil-230				
005	000	Denmark	Denmark	029	Slovakia	Brazil-254			
	001		DK-TR322			003	Brazil-288		
006	000	Greece	GR-Continent	030		SK-VDS			
	001		GR-Island			001	SK-SSE		
007	000	Netherlands	Netherlands	031-032		SK-ZSD			
	001		Netherland-MV			000			
	002		Netherland-HV			033	Ukraine		
008	000	Belgium	Belgium	034	Norway	Norway			
	001		Belgium-HV			001	Norway-LV		
009	000	UK	G99	035	Mexico	Mexico-LV			
	001		G98			036-037			
	002		G99-HV			038	60Hz		
010	000	China	China-B	039	Ireland EN50438	Ireland			
	001		Taiwan			000	Thailand	Thailand	
	002		TrinaHome	040	001		Thailand-MEA		
	003		HongKong			041			
	004		SKYWORTH	042	000	50Hz	LV-50Hz		
	005		CSISolar	043					
	006		CHINT	044	000	South Africa	SA		
	007		China-MV				001	SA-HV	
	008		China-HV	045					
	009		China-A				046	000	Dubai
011	000	France	France	047-106		DEWG-MV			
	001		FAR Arrete23						
	002		FR VDE0126-HV			107	000	Croatia	Croatia
	003		France VFR 2019			108	000	Lithuania	Lithuania
012	000	Poland	Poland	109	000				
	001		Poland-MV	110					
	002		Poland-HV	111	000	Columbia	Columbia		
	003		Poland-ABCD				001	Columbia-LV	
013	000	Austria	Tor Erzeuger	112-120					
014	000	Japan		121	000	Saudi Arabia	IEC62116		
	001			122	000	Latvia			
015	003	Switzerland		123	000	Romania			
16-17									

Table 18 - List of country codes



3.2.4. Setting the input channels

Input Channel Config			
OK ↓	Input Channel1	Bat input 1	Up↑ Do wn↓
		Bat input 2	
		Not used	
OK ↓	Input Channel2	Bat input 1	Up↑ Do wn↓
		Bat input 2	
		Not used	
OK ↓	Input Channel3	PV input 1	Up↑ Do wn↓
		PV input 2	
		Not used	
OK ↓	Input Channel4	PV input 1	Up↑ Do wn↓
		PV input 2	
		Not used	

In the case of a **single Pylontech or Azzurro battery tower**, set the inputs according to the channel populated:

- Input channel 1 → BAT input 1 (if the channel populated is no. 1)
- Input channel 2 → Not Used

In the case of a **single WeCo battery tower or double Pylontech tower (Wi-Fi/USB SC500 or Wi-Fi/USB SC1000 BMS)**, set the inputs by populating both channels:

- Input channel 1 → BAT input 1
- Input channel 2 → BAT input 2

In the case of **dual battery tower (Pylontech SC500 or SC1000 BMS, WeCo, Azzurro)** set the inputs:

- Input channel 1 → BAT input 1
- Input channel 2 → BAT input 2

For independent strings, set:

- Input channel 3 → PV input 1
- Input channel 4 → PV input 2

For parallel strings, set:

- Input channel 3 → PV input 1
- Input channel 4 → PV input 1



3.2.5. Setting battery parameters

	Single Azzurro battery tower	Single Pylontech battery tower	Single WeCo battery tower	Dual battery tower PYLON SC500 or SC1000/WECO/AZZURRO BMS		Dual battery tower PYLON Wi-Fi/USB SC500 or Wi-Fi/USB SC1000 BMS
Battery identification	Battery 1	Battery 1	Battery 1	Battery 1	Battery 2	Battery 1
1.Battery Type	HV ZBT	PYLON	WECO	PYLON/WECO/HV ZBT	PYLON/WECO/HV ZBT	PYLON
2.Battery Address	00	00	00	00	01	01
3.Max Charge (A)	25.00	25.00	50.00	25.00	25.00	50.00
4.Max Discharge (A)	25.00	25.00	50.00	25.00	25.00	50.00
5.Discharge Depth	max 90%	max 80%	max 90%	max 90%	max 90%	max 80%
6.Save	ok	ok	ok	ok	ok	ok

Item	Default state
Energy Storage Mode	Self-use mode
EPS Mode	Disable
Anti Reflux	Disable
IV Curve Scan	Disable
Logic interface	Disable

Table 19 - Default values for other settings



3.3. Main menu





Figure 208 - Main menu interface

From the main interface, press the “Down” key to enter the page with the grid/battery settings.



Batt1 Power.....**.*KW
Batt1 Temp.....*°C
Batt1 SOC.....**%
Batt1 SOH.....**%
Batt1 Cycles.....*T
Battery Information (2)
Batt2 (V).....****.*V
Batt2 Curr.....**.*A
Batt2 Power.....**.*KW
Batt2 Temp.....*°C
Batt2 SOC.....**%
Batt2 SOH.....**%
Batt2 Cycles.....*T

Down↓

From the main interface, press the “Up” key to enter the page with the photovoltaic settings.

Main interface	Up↑	PV Information
		PV1 Voltage.....****.*V
		PV1 Current.....**.*A
		PV1 Power.....**.*KW
		PV2 Voltage.....****.*V
		PV2 Current.....**.*A
		PV2 Power.....**.*KW



Inverter Temp.....*°C

From the main interface, press the “Back” key to enter the main menu, which has the following 5 options.

Main menu

Back

- | |
|-------------------------|
| 1.Basic settings |
| 2.Advanced settings |
| 3.Production Statistics |
| 4.System Info |
| 5.Event list |
| 6.Software Update |



3.3.1. Basic settings

1. Basic settings

OK

1. Language Settings
2. Time
3. Safety Param.
4. Working Mode
5. Self-test
6. Channel configuration
7. EPS mode
8. Communication address
9. Set ForceChargeTime

1. Language settings

1. Language Settings

OK

1. 中文
2. English
3. Italian
4.
.....

OK

2. Time

Set the system time for the inverter

2. Time

OK

Time
YYYY-MM-DD hh:mm:ss

3. Safety parameters

The user can modify the safety parameters of the machine via a USB stick, and must copy and modify the values on the USB stick beforehand.

For more information and/or clarification, contact Zucchetti Centro Sistemi S.p.A.



4. Working mode

4.Working Mode	1. Automatic mode	OK
	5.% Charge mode	
	3.Hourly mode	
	4.Passive mode	

Automatic mode

The inverter automatically charges and discharges the battery.

If the PV generation (kW) = consumption (kW), with $\Delta P < 200W$, the inverter does not charge or discharge the battery (Figure a).

If the PV generation (kW) > consumption (kW), the power surplus is stored in the battery (Figure b).




Figure 209 - Inverter display in automatic mode



If the PV generation (kW) < consumption (kW), the battery is discharged to provide the necessary power, until it is completely discharged (Figure a).
 If the battery is fully charged (or at maximum charging power), the surplus power is transferred to the grid (Figure b).




Figure 210 - Inverter display in automatic mode

If the PV generation + battery (kW) < consumption (kW), the inverter draws power from the grid.




Figure 211 - Inverter display in self-consumption mode

Times of use

For a more rational management of the energy (especially in winter, where the photovoltaic system cannot effectively charge the battery), it may be necessary to set a date range for recharging the battery from the grid; once this range has been set, the inverter will operate in automatic mode for the remaining time.



Dates, days and times can be set in which to force charge the batteries up to the set SOC %.

2.% charge mode	OK	% charge mode			
		Rules. 0: Enabled/Disabled			
		From	To	SOC	Charge
		02h00m - 04h00m		070%	01000 W
		Effective date			
		Dec. 22	-	Mar. 21	
		Weekday select			
		Mon. Tue. Wed. Thu.			
		Fri. Sat. Sun.			

Timed Use

The time range in which to charge and discharge the battery can be set manually.

3.Hourly mode	OK	Hourly mode			
		Rules. 0:Enabled/Disabled			
		Charge Start			22 h 00 m
		Charge End			05 h 00 m
		Charge Power			02000 W
		Discharge Start			14 h 00 m
		Discharge End			16 h 00 m
		Discharge Power			02500 W

Passive Use

Passive mode allows the inverter to see the batteries but not to charge or discharge them. This setting is useful for the initial testing of the inverter. For more detailed information on passive operation, please contact Zucchetti Centro Sistemi S.p.A.



5. Self-test

5.Self-test	OK	1.Fast self-test
		2.STD self-test

The fast self-test gives the same results as the STD (standard) self-test, but takes less time.

1. Fast self-test	OK	Start Self-test	Press "Ok" to start
		Testing 59.S1...	
		↓	Wait
		Test 59.S1 OK!	
		↓	Wait
		Testing 59.S2...	
		↓	Wait
		Test 59.S2 OK!	
		↓	Wait
		Testing 27.S1...	
		↓	Wait
		Test 27.S1 OK!	
		↓	Wait
		Testing 27.S2...	
		↓	Wait
Test 27.S2 OK!			
↓	Wait		
Testing 81>S1...			





↓	Wait
Test 81>S1 OK!	
↓	Wait
Testing 81>S2...	
↓	Wait
Test 81>S2 OK!	
↓	Wait
Testing 81<S1...	
↓	Wait
Test 81<S1 OK!	
↓	Wait
Testing 81<S2...	
↓	Wait
Test 81<S2 OK!	
↓	Press "Ok"
OK self-test!	
↓	Press "Down"
59.S1 threshold 253V 900ms	
↓	Press "Down"
59.S1: 228V 902ms	
↓	Press "Down"
59.S2 threshold 264.5V 200ms	
↓	Press "Down"





59.S2: 229V 204ms	
↓	Press "Down"
27.S1 threshold 195.5V 400ms	
↓	Press "Down"
27.S1: 228V 408ms	
↓	Press "Down"
27.S2 threshold 92V 200ms	
↓	Press "Down"
27.S2: 227V 205ms	
↓	Press "Down"
81>.S1 threshold 50.5Hz 100ms	
↓	Press "Down"
81>.S1 49.9Hz 103ms	
↓	Press "Down"
81>.S2 threshold 51.5Hz 100ms	
↓	Press "Down"
81>.S2 49.9Hz 107ms	
↓	Press "Down"
81<.S1 threshold 49.5Hz 100ms	
↓	Press "Down"
81<.S1 50.0Hz 105ms	
↓	Press "Down"





81<.S2 threshold 47.5Hz 100ms
↓
81<.S2 50.1Hz 107ms

Press "Down"

6. Configuration of input channel

6.Channel configuration

OK

Input Channel Config	
Input Channel1	Battery input 1
	Battery input 1
	Disable
Input Channel2	Battery input 2
	Battery input 2
	Disable
Input Channel3	PV input 1
	PV input 1
	Disable
Input Channel4	PV input 2
	PV input 2
	Disable

Down OK


Down

Down

Down



7. EPS Mode



If the PV generation (kW) > consumption (kW), with $\Delta P < 200W$, the inverter charges the battery (Figure a).

If the PV generation (kW) = consumption (kW), the inverter does not charge or discharge the battery (Figure b).




Figure 212 - Display with EPS in operation

If the PV generation (kW) < consumption (kW), with $\Delta P < 200W$, the inverter discharges the battery (Figure a).

If the PV generation (kW) is normal, but consumption (kW) is lower or zero, the power surplus is stored in the battery (Figure b).




Figure 213 - Display with EPS in operation



8. Communication address

8.Communication address	OK	1.Communication Addr	OK
		2.Baud Rate	OK

9. Setting of forced charge time

9.Set ForceChargeTime	OK	Charge Start	OK
		Charge End	OK

3.3.2.Advanced settings

2.Advanced settings	OK	Password 0715	
		1.Battery parameters	
		2.Zero feed-in mode	
		3.IV Curve Scan	
		4.Logic interface	
		5.Factory reset	
		6. Parallel settings	
		7. Bluetooth Reset	
		8. CT Calibration	
		9. On-Off switch	
		10.Unbalanced support	
		11.PV priority charging	



12. EPS GFCI
13. Auxiliary contact
14.Active battery

1. Battery parameters

1. Battery parameters	OK	1.Battery type	4.Maximum discharge (A)	OK
		2.Battery address	5.Depth of Discharge	
		3.Maximum charge (A)	6.Save	

Depth of Discharge (DOD)

e.g. DOD = 50% and EPS = 80%

While the grid is connected, the inverter will not discharge the battery as long as the SOC is less than 50%.

In the event of a blackout, the inverter operates in EPS mode (if EPS is enabled) and continues to discharge the battery until it reaches a battery SOC of 20%.

5.Depth of Discharge	OK	Depth of discharge 50% EPS depth of discharge 80% EPS Safety Buffer 20%
----------------------	----	--

2. Zero feed-in mode

Depending on the software version of the inverter, this function may be called **Anti-Reflux** or **Feed-in**. "Zero feed-in" mode can be enabled to limit the maximum power exported to the grid. The power set is the maximum power to be fed into the grid.



2.Zero feed-in	OK	2.Zero feed-in control	OK	Enable
				Disable
		2.Feed-in power	OK	***KW

3. IV Curve Scan

The IV curve scan (MPPT scan) can be enabled to find the maximum overall power by adjusting the value during operation in order to obtain maximum output from the panels even in suboptimal conditions. A scan period can be set or an instant scan can be performed.

3.IV Curve Scan	OK	1.Scan control	OK	Enable
				Disable
		2.Scan period	OK	***min
		3.Force Scan	OK	

4. Logic Interface Control

To enable or disable logic interfaces, refer to the chapter on connections between logic interfaces (Section 2, page 173).

This setting must always be disabled for systems installed in Italy.

4.Logic interface control	OK	Enable	OK
		Disable	OK

5. Reset factory settings

5.Factory reset	OK	1.Reset Energy Data	OK
		2.Clear events	OK

Delete the history of total power generated by the inverter.

1.Reset Energy Data	OK	Enter password	OK Password 0715
---------------------	----	----------------	-------------------------



Delete history of errors recorded on the inverter.

2.Reset events OK

Clear Events? OK

6. Parallel inverter settings

This setting is to be enabled for systems that have multiple hybrid inverters connected in parallel (Master – Slave)

6.Parallel settings OK

1.Parallel settings	Enable/disable
2.Master-Slave Parallel	Primary / Replica
1.Parallel address	00 (Primary) 01 (replica 1) ... 0n (Replica n)
4.Save	ok

7. Reset Bluetooth

Function to be implemented.

8. CT Calibration

In a three-phase hybrid system, the R, S and T phases of the inverter must correspond to the R, S and T phases embraced by the CT sensors.

If you are not sure whether this is the case, you can enable the CT calibration function.

For the inverter to perform this operation, it is necessary that:

- The system is connected to the grid
- The load output is not powered
- The batteries are present and switched on and at a maximum SOC of 40% to 80% (with depth of discharge $\leq 20\%$)
- The loads in the system are switched off
- Photovoltaic production is switched off
- Any other external production sources are switched off

In this way, the system will automatically set internally both the position of each sensor in the correct phase and the direction in line with the system's current flows.

ATTENTION!!!!: CT calibration may take several minutes, do not switch off the inverter while it is performing this operation

We recommend that you consult with ZCS technicians before enabling this function.

9. On-Off switch

This function enables a forced standby of the system (do not enable this function).

10. Unbalanced support

To enable this function, it is necessary that:

1. Zero feed-in mode is enabled;
2. In the case of toroids at the exchange reading (CT) connected directly to the inverter, make sure that the R, S and T phases of the inverter are the same as the R, S and T phases embraced by the sensors;
3. In the case of a Meter at the exchange reading (DTSU), make sure that R, S and T phases of the inverter are the same as the A, B and C phases of the Meter;
4. There are batteries connected to the inverter.

This function allows the zero feed-in function to be used even with unbalanced phases (the unbalancing limit depends on the power of the inverter, e.g. a 10 kW inverter can unbalance the phases up to a maximum of 3.33kW per phase).

10. PV priority charging

When the batteries have reached the DoD, this setting allows the PV power to give priority to the batteries by supplying 200W until the Safety Buffer is reached.

11. EPS GFCI

In EPS mode, this function allows the system to detect ground leakage currents even if it is an IT system.

12. Auxiliary contact

This function allows the dry contacts in the COM port to be managed.



14. Active battery

This function must always be enabled.





3.3.3.Event list

The event list shows the events in real time, with a progressive number, date and time and type of error. The list of errors can be checked through the main menu to monitor the details of the event history in real.



3.3.4.System interface information

The system information allows you to check the settings that have been assigned to the inverter and batteries. After installation, it is recommended to check that all the settings have been set correctly.





Down↓	Inverter Info (2)
	SW Version: press enter (password 0715) to display the firmware version of the inverter
	Country
	Country code version
Down↓	Inverter Info (3)
	Input Channel1
	Input Channel2
	Input Channel3
Down↓	Inverter Info (4)
	Working mode
	RS485 Modbus Address
	EPS Mode
Down↓	IV Curve Scan
	Inverter Info (5)
	Logic interface
	Default PV time
Down↓	Default QV time
	Power factor
	Inverter Info (6)
	Zero feed-in limitation
Down↓	Insulation resistance





Parallel control
Unbalanced support
Inverter Info (7)
Active battery

2.Battery info

OK

Batt Info (1)
Battery type
Battery address
Battery capacity
Depth of discharge
Batt Info (2)
Max charge current (A)
Max charge threshold (V)
Max discharge current (A)
Min discharge voltage (V)

Down↓

3.Safety Parameters

OK

Safety parameters (1)
OVP 1
OVP 2
UVP 1
UVP 2
Safety parameters (2)
OFP 1

Down
↓





Down
↓

OFP 2
UFP 1
UFP 2
Safety parameters (3)
OVP 10mins

3.3.5. Energy statistics

6. Energy Statistics

OK

Down
↓

Down
↓

Today
PV***KWH
Load***KWH
Export***KWH
Import.....***KWH
Charge.....***KWH
Discharge.....***KWH
Month
PV***KWH
Load***KWH
Export***KWH
Import.....***KWH
Charge.....***KWH
Discharge.....***KWH
Year





PV***KWH
Load***KWH
Export***KWH
Import.....***KWH
Charge.....***KWH
Discharge.....***KWH
Life
PV***KWH
Load***KWH
Export***KWH
Import.....***KWH
Charge.....***KWH
Discharge.....***KWH


Down
↓



3.3.6. Software Update

On first installation, all Zucchetti hybrid inverters must be updated to the latest firmware version found in the www.zcsazzurro.com website, unless the inverter is already updated to the version on the website or to a later version (see image below).

Do not update the inverter if its firmware version is the same or higher than the one found in the ZCS Azzurro website




ATTENTION!!! Downgrading the firmware version of the inverter could lead to a malfunction.

3PH HYD5000-HYD20000-ZSS inverters must be upgraded using an 8 GB USB stick.

Procedure:

1. Insert the USB stick into the computer
2. Download the firmware of your inverter from the products section (storage inverters) of the www.zcsazzurro.com website, selecting the inverter model you own
3. Save only the firmware folder containing the .bin files on the USB stick.
4. Safely remove the USB stick from the computer
5. Make sure the inverter is switched off
6. Insert the USB stick in the appropriate USB port of the inverter
7. Switch on the inverter by turning the inverter's DC rotary switch to ON

8.



9. If any of the errors listed below appear, repeat the operation. If this happens several times, contact the support service.

USB Fault	MDSP File Error	SDSP File Error
ARM File Error	Update DSP1 Fail	Update DSP2 Fail
Update ARM Fail		

Table 20 - Software update errors

10. After updating the inverter, use the same procedure as above to load the safety files onto the USB stick and set the correct safety parameters.
11. After completing the update and setting the correct safety parameters, close the DC switch, wait for the LCD screen to turn off; then restore the Wi-Fi connection and open both the DC and AC switches, wait a few seconds for the inverter to switch on again. To check the current version of the system update, go to System Info > Software Version.



5. Technical data

5.1. 3PH HYD5000-HYD8000-ZSS technical data

DATI TECNICI	3PH HYD5000 ZSS	3PH HYD6000 ZSS	3PH HYD8000 ZSS
Dati tecnici ingresso DC (fotovoltaico)			
Potenza DC Tipica*	7500W	9000W	12000W
Massima Potenza DC per ogni MPPT	6000W (480V-850V)	6600W (530V-850V)	6600W (530V-850V)
N. MPPT indipendenti/ N. stringhe per MPPT		2/1	
Tensione massima di ingresso		1000V	
Tensione di attivazione		250V	
Tensione nominale di ingresso		600V	
Intervallo MPPT di tensione DC		180V-960V	
Intervallo di tensione DC a pieno carico	250V-850V	320V-850V	360V-850V
Massima corrente in ingresso per ogni MPPT		12.5A/12.5A	
Massima corrente assoluta per ogni MPPT		15A/15A	
Dati tecnici collegamento batterie			
Tipo di batteria compatibile		Ioni di litio (fornite da Zucchetti)	
Intervallo di tensione ammessa		180V-750V	
Numero di canali batteria indipendenti		1	
Massima potenza di carica/scarica	5000W	6000W	8000W
Range di temperatura ammessa**		-10°C/+50°C	
Massima corrente di carica per canale batteria		25A (40A di picco per 60s)	
Massima corrente di scarica per canale batteria		25A (40A di picco per 60s)	
Curva di carica		Gestita da BMS batteria	
Profondità di scarica (DoD)		0%-90% (programmabile)	
Uscita AC (lato rete)			
Potenza nominale	5000W	6000W	8000W
Potenza massima	5500VA	6600VA	8800VA
Massima corrente	8A	10A	13A
Tipologia connessione/ Tensione nominale		Trifase 3/N/PE, 220/380, 230/400	
Intervallo di tensione AC		184V-276V (in accordo con gli standard locali)	
Frequenza nominale		50Hz/60Hz	
Intervallo di frequenza AC		45Hz-55Hz / 55Hz-65Hz (in accordo con gli standard locali)	
Distorsione armonica totale		<3%	
Fattore di potenza		1 default (programmabile +/- 0.8)	
Limitazione immissione in rete		Programmabile da display	
Uscita EPS (Emergency Power Supply)			
Potenza erogata in EPS***	5000W	6000W	8000W
Potenza apparente di picco in EPS***	10000VA per 60s	12000VA per 60s	16000VA per 60s
Tensione e frequenza uscita EPS		Trifase 230V/400V 50Hz	
Corrente erogabile in EPS (di picco)	8A (15A per 60s)	10A (18A per 60s)	13A (24A per 60s)
Distorsione armonica totale		3%	
Switch time		<20ms	
Efficienza			
Efficienza massima		98.0%	
Efficienza peseta (EURO)		97.5%	
Efficienza MPPT		99.9%	
Massima efficienza di carica/scarica delle batterie		97.6%	
Consumo in stand-by		<15W	
Protezioni			
Protezione di interfaccia interna		si	
Protezioni di sicurezza		Anti islanding, RCMU, Ground Fault monitoring	
Protezione da inversione di polarità DC		si	
Sezionatore DC		integrato	
Protezione da surriscaldamento		si	
Categoria Sovratensione/ Tipo di protezione		Overvoltage Category III / Protective class I	
Scaricatori integrati		AC/DC MOV: Tipo 2 standard	
Protezione da sovracorrenti in uscita		si	
Soft Start Batteria		si	
Standard			
EMC		EN61000-1, EN61000-3	
Safety standard		IEC62109-1, IEC62109-2, NB-T32004/IEC62040-1	
Standard di connessione alla rete		Certificati e standard di connessione disponibili su www.zcsazurro.com	
Comunicazione			
Interfacce di comunicazione	Wi-Fi/4G/Ethernet (opzionali), RS485 (protocollo proprietario), USB, CAN 2.0 (per collegamento con batterie), Bluetooth		
Altri ingressi	Linea RS485 per Meter esterni (fino a 4 meter collegabili), 6 input digitali (5V TTL), connessione per sensori diretti (CT)		
Dati Generali			
Intervallo di temperatura ambiente ammesso		-30-60 °C	
Topologia		Transformerless	
Grado di protezione ambientale		IP65	
Intervallo di umidità relativa ammesso		0-100%	
Massima altitudine operativa		4000m	
Rumorosità		<45 dB @ 1m	
Peso		33Kg	
Raffreddamento		Convezione naturale	
Dimensioni (H*L*P)		515mm*571mm*264mm	
Display		LED display e APP	
Garanzia		10 anni	

* La potenza DC tipica non rappresenta un limite massimo di potenza applicabile. Il configuratore online disponibile sul sito www.zcsazurro.com fornirà le possibili configurazioni applicabili

** Valore standard per batterie al litio; massima operatività tra +10°C/+40°C

*** La potenza erogata in EPS dipende dal numero e dal tipo di batterie nonché dallo stato del sistema (capacità residua, temperatura)



5.2. 3PH HYD10000-HYD20000-ZSS technical data

DATI TECNICI	3PH HYD10000 ZSS	3PH HYD15000 ZSS	3PH HYD20000 ZSS
Dati tecnici ingresso DC (fotovoltaico)			
Potenza DC Tipica*	15000W	22500W	30000W
Massima Potenza DC per ogni MPPT	7500W (300V-850V)	11250W (450V-850V)	15000W (600V-850V)
N. MPPT indipendenti/ N. stringhe per MPPT		2/2	
Tensione massima di ingresso		1000V	
Tensione di attivazione		250V	
Tensione nominale di ingresso		600V	
Intervallo MPPT di tensione DC		180V-960V	
Intervallo di tensione DC a pieno carico	220V-850V	350V-850V	450V-850V
Massima corrente in ingresso per ogni MPPT		25A/25A	
Massima corrente assoluta per ogni MPPT		30A/30A	
Dati tecnici collegamento batterie			
Tipo di batteria compatibile	Ioni di litio (fornite da Zucchetti)		
Intervallo di tensione ammessa	180V-750V		
Numero di canali batteria indipendenti	2 canali batteria HV (configurabili come indipendenti o in parallelo)		
Massima potenza di carica/scarica	10000W	15000W	20000W
Range di temperatura ammessa**	-10°C/+50°C		
Massima corrente di carica per canale batteria	25A (25A di picco per 60s)		
Massima corrente di scarica per canale batteria	25A (25A di picco per 60s)		
Curva di carica	Gestita da BMS batteria		
Profondità di scarica (DoD)	0%-90% (programmabile)		
Uscita AC (lato rete)			
Potenza nominale	10000W	15000W	20000W
Potenza massima	11000VA	16500VA	22000VA
Massima corrente	16A	24A	32A
Tipologia connessione/ Tensione nominale	Trifase 3/N/PE, 220/380, 230/400		
Intervallo di tensione AC	184V-276V (in accordo con gli standard locali)		
Frequenza nominale	50Hz/60Hz		
Intervallo di frequenza AC	45Hz-55Hz / 55Hz-65Hz (in accordo con gli standard locali)		
Distorsione armonica totale	<3%		
Fattore di potenza	1 default (programmabile +/- 0.8)		
Limitazione immissione in rete	Programmabile da display		
Uscita EPS (Emergency Power Supply)			
Potenza erogata in EPS***	10000W	15000W	20000W
Potenza apparente di picco in EPS***	20000VA per 60s	22000VA per 60s	22000VA per 60s
Tensione e frequenza uscita EPS	Trifase 230V/400V 50Hz		
Corrente erogabile in EPS (di picco)	16A (30A per 60s)	24A (32A per 60s)	32A (33A per 60s)
Distorsione armonica totale	3%		
Switch time	<20ms		
Efficienza			
Efficienza massima	98.2%		
Efficienza pesata (EURO)	97.7%		
Efficienza MPPT	99.9%		
Massima efficienza di carica/scarica delle batterie	97.8%		
Consumo in stand-by	<15W		
Protezioni			
Protezione di interfaccia interna	si		no
Protezioni di sicurezza	Anti islanding, RCMU, Ground Fault monitoring		
Protezione da inversione di polarità DC	si		
Sezionatore DC	integrato		
Protezione da surriscaldamento	si		
Categoria Sovratensione/ Tipo di protezione	Overvoltage Category III / Protective class I		
Scaricatori integrati	AC/DC MOV: Tipo 2 standard		
Protezione da sovracorrenti in uscita	si		
Soft Start Batteria	si		
Standard			
EMC	EN61000-1, EN61000-3		
Safety standard	IEC62109-1, IEC62109-2, NB-T32004/IEC62040-1		
Standard di connessione alla rete	Certificati e standard di connessione disponibili su www.zcsazzurro.com		
Comunicazione			
Interfacce di comunicazione	Wi-Fi/4G/Ethernet (opzionali), RS485 (protocollo proprietario), USB, CAN 2.0 (per collegamento con batterie), Bluetooth		
Altri ingressi	Linea RS485 per Meter esterni (fino a 4 meter collegabili), 6 input digitali (5V TTL), connessione per sensori diretti (CT)		
Dati Generali			
Intervallo di temperatura ambiente ammesso	-30-60 °C		
Topologia	Transformerless		
Grado di protezione ambientale	IP65		
Intervallo di umidità relativa ammesso	0-100%		
Massima altitudine operativa	4000m		
Rumorosità	<45 dB @ 1m		
Peso	37Kg		
Raffreddamento	Convezione forzata		
Dimensioni (H*L*P)	515mm*571mm*264mm		
Display	LED display e APP		
Garanzia	10 anni		


* La potenza DC tipica non rappresenta un limite massimo di potenza applicabile. Il configuratore online disponibile sul sito www.zcsazzurro.com fornirà le possibili configurazioni applicabili

** Valore standard per batterie al litio; massima operatività tra +10°C/+40°C

*** La potenza erogata in EPS dipende dal numero e dal tipo di batterie nonché dallo stato del sistema (capacità residua, temperatura)

6. Troubleshooting

This section contains information and procedures for troubleshooting any problems and errors signalled by the inverter.

	Read the following section carefully. Check the warnings, messages and error codes shown on the screen.
Attention	

If no errors are found, check that certain basic conditions are met before proceeding. **Any type of check must be carried out safely according to the specific procedure.**

- Is the inverter located in a clean, dry place with good ventilation?
- Is the DC circuit breaker ON?
- Do the cables have the appropriate cross-section and length?
- Are the input and output connections in good condition?
- Are the configuration and settings correct for this type of installation?
- Are the communication system and display free of damage?

If all these requirements are met, proceed with the steps for viewing any errors.

Ground connection error

The 3PH HYD5000-HYD20000-ZSS inverters comply with the IEC 62109-2 standard for earth alarm fault monitoring.

If the ground connection error appears, it will be displayed on the LCD screen, the red light will turn on and the error will appear in the event list. For devices fitted with Wi-Fi/GPS, the alarm can also be displayed on the monitoring site and also notified on the mobile app.



Code	Name	Description	Solution
ID001	GridOVP	The grid voltage is too high.	<p>If the error occurs occasionally, there may be abnormal fluctuations in the grid, the inverter returns to normal operation as soon as the grid returns to normal conditions.</p> <p>If the alarm occurs frequently, check whether the grid voltage and frequency are within acceptable ranges. If so, check the AC switch and the AC connection to the inverter. If the grid voltage and frequency are within acceptable ranges and the AC connection is correct, but the alarm persists, contact technical support to change the values of overvoltage, undervoltage, maximum frequency, minimum frequency, after obtaining the approval of the local grid operator.</p>
ID002	GridUVP	The grid voltage is too low.	
ID003	GridOFP	The grid frequency is too high.	
ID004	GridUFP	The grid frequency is too low.	
ID005	GFCI	Loss of charge	<p>Internal inverter errors. Check whether the inverter is updated to the latest version found on www.zcsazzurro.com. If it isn't, update to the latest version. If the errors still occur, contact technical support</p>
ID006	OVRT fault	OVRT function in error	
ID007	LVRT fault	LVRT function in error	
ID008	IslandFault	Isolation error	
ID009	GridOVPIstant1	Transient overvoltage of grid 1	
ID010	GridOVPIstant2	Transient overvoltage of grid 2	
ID011	VGridLineFault	Grid voltage error	
ID012	InvOVP	Inverter overvoltage	
ID017	HwADFaultIGrid	Error in the measurement of the grid current	

ID018	HwADFaultDCI	Measurement error of the DC component of the grid current	
ID019	HwADFaultVGrid(DC)	Grid voltage (DC) measurement error	
ID020	HwADFaultVGrid(AC)	Grid voltage (AC) measurement error	
ID021	GFCIDeviceFault(DC)	Current (DC) leakage measurement error	
ID022	GFCIDeviceFault(AC)	Current (AC) leakage measurement error	
ID023	HwADFaultDCV	Measurement error of the DCI component of the charge voltage	
ID024	HwADFaultIdc	Input current measurement error	Check that the polarity on the DC side has not been inverted.
ID029	ConsistentFault_GFCI	Leakage current reading error	Internal inverter errors. Check whether the inverter is updated to the latest version found on www.zcsazzurro.com . If it isn't, update to the latest version. If the errors still occur, contact technical support
ID030	ConsistentFault_Vgrid	Grid voltage reading error	
ID033	SpiCommFault(DC)	SPI communication error (DC)	
ID034	SpiCommFault(AC)	SPI communication error (AC)	
ID035	SChip_Fault	Chip error (DC)	
ID036	MChip_Fault	Chip error (AC)	
ID037	HwAuxPowerFault	Auxiliary power error	
ID038	InvSoftStartFail	Internal error	
ID041	RelayFail	Relay detection error	
ID042	IsoFault	Low impedance isolation	
ID043	PEConnectFault	Ground fault	Check the AC-side of the PE output for grounding

ID044	PvConfigError	Error in input mode setting.	Check the mode of the PV input (parallel/independent); if they are not correct, change them.
ID045	CTDisconnect	CT error	Check whether the CT connection is correct.
ID047	ParallelFault	Parallel settings error	Check whether the connection between the inverters is correct and whether the terminating resistors have been connected at the beginning and end of the parallel. Check that the parameters have been set to advanced settings, check that the parallel connection is correct. Check that all the inverters in parallel are updated to the same firmware version.
ID049	TempFault_Bat	Battery temperature protection	Make sure that the inverter is installed in a cool, well-ventilated place, below the temperature limits and away from direct sunlight. Check that the inverter has been installed according to the instructions in the manual.
ID050	TempFault_HeatSink1	Radiator temperature protection 1	
ID051	TempFault_HeatSink2	Radiator temperature protection 2	
ID052	TempFault_HeatSin3	Radiator temperature protection 3	
ID053	TempFault_HeatSink4	Radiator temperature protection 4	
ID054	TempFault_HeatSin5	Radiator temperature protection 5	
ID055	TempFault_HeatSin6	Radiator temperature protection 6	
ID057	TempFault_Env1	Ambient temperature protection 1	
ID058	TempFault_Env2	Ambient temperature protection 2	
ID059	TempFault_Inv1	Module temperature protection 1	
ID060	TempFault_Inv2	Module 2 temperature protection	
ID061	TempFault_Inv3	Module temperature protection 3	
ID065	VbusRmsUnbalance	RMS bus voltage is not balanced	



ID066	VbusInstantUnbalance	Transient voltage value of the BUS is not balanced	version found on www.zcsazzurro.com . If it isn't, update to the latest version. If the errors still occur, contact technical support
ID067	BusUVP	Busbar undervoltage during grid connection	
ID068	BusZVP	Low BUS voltage	
ID069	PVOVP	PV overvoltage	Check whether the voltage of the PV modules in series (Voc) is higher than the maximum input voltage. If so, adjust the number of PV modules in series to reduce the voltage of the PV modules in series, adapting them to the input voltage range of the inverter. After changing the voltage, the inverter returns to normal operation on its own.
ID070	BatOVP	Batter overvoltage	Check that the battery overvoltage settings are compatible with the battery specifications.
ID071	LLCBusOVP	LLC Bus overvoltage protection	Internal inverter errors. Switch it off, wait 5 minutes and switch it on again. If the errors still occur, contact technical support.
ID072	SwBusRmsOVP	Software RMS overvoltage protection of the DC bus	
ID073	SwBusInstantOVP	Software instantaneous overvoltage protection of the DC bus	Check that the Load input and the Grid output have not been inverted.
ID081	SwBatOCP	Battery software overcurrent protection	Check that the zero feed-in has not been disabled without also having disabled the unbalance support. If so, also disable the latter, otherwise check whether the inverter is updated to the latest version found on www.zcsazzurro.com . If it isn't, update to the latest version. If the errors still occur, contact technical support.
ID082	DciOCP	Dci overcurrent protection	
ID083	SwOCPIstant	Instantaneous output current protection	
ID084	SwBuckBoostOCP	BuckBoost software flow	

ID085	SwAcRmsOCP	Current actual value protection	
ID086	SwPvOCPIstant	Software PV overcurrent protection	
ID087	IpvUnbalance	Parallel PV flows not balanced	
ID088	IacUnbalance	Output current not balanced	
ID097	HwLLCBusOVP	LLC bus hardware overvoltage	
ID098	HwBusOVP	Bus hardware overvoltage	
ID099	HwBuckBoostOCP	Excessive BuckBoost hardware flows	
ID100	HwBatOCP	Excessive battery hardware flows	
ID102	HwPVOCP	Excessive PV hardware flows	
ID103	HwACOCP	Excessive AC hardware output flows	
ID110	Overload1	Overload protection 1	Check whether the inverter is running in overload
ID111	Overload2	Overload protection 2	
ID112	Overload3	Overload protection 3	
ID113	OverTempDerating	Internal temperature too high.	Make sure that the inverter is installed in a cool, well-ventilated place, below the temperature limits and away from direct sunlight. Check that the inverter has been installed according to the instructions in the manual.
ID114	FreqDerating	AC frequency is too high.	Make sure that the grid frequency and voltage are within the acceptable range

ID115	FreqLoading	AC frequency is too low	
ID116	VoltDerating	AC voltage is too high	
ID117	VoltLoading	AC voltage is too low	
ID124	BatLowVoltageAlarm	Low battery voltage protection	Check that the battery voltage on the inverter side is not too low (this alarm is normal if the battery has reached the set depth-of-discharge threshold).
ID125	BatLowVoltageShut	Battery shutdown due to low voltage	
ID129	unrecoverHwAcOCP	Permanent hardware error due to output overcurrent	Internal inverter errors. Check whether the inverter is updated to the latest version found on www.zcsazzurro.com . If it isn't, update to the latest version. If the errors still occur, contact technical support
ID130	unrecoverBusOVP	Fixed bus overvoltage error	
ID131	unrecoverHwBusOVP	Bus hardware overvoltage error	
ID132	unrecoverIpvUnbalance	Permanent unbalanced PV flow error	
ID133	unrecoverEPSBatOCP	Permanent battery overcurrent error in EPS mode	
ID134	unrecoverAcOCPInstant	Transient battery output overcurrent error	
ID135	unrecoverIacUnbalance	Permanent unbalanced output current error	
ID137	unrecoverPvConfigError	Permanent error in input mode settings	Check the mode of the PV input (parallel/independent); if they are not correct, change them.
ID138	unrecoverPVOCPInstant	Permanent input overcurrent error	
ID139	unrecoverHwPVOCP	Permanent hardware overcurrent error	Internal inverter errors. Check whether the inverter is updated to the latest version found on www.zcsazzurro.com . If it isn't, update to the latest version. If the errors still occur, contact technical support
ID140	unrecoverRelayFail	Permanent relay error	
ID141	unrecoverVbusUnbalance	Permanent unbalanced bus voltage error	
ID145	USBFault	USB error	Check the USB input of the inverter. Switch it off, wait 5 minutes and switch it on again. If the errors still occur, contact technical support
ID146	WifiFault	WiFi error	Check the Wi-Fi input of the inverter. Switch it off, wait 5 minutes and switch

			it on again. If the errors still occur, contact technical support
ID147	BluetoothFault	Bluetooth error	Check whether the inverter is updated to the latest version found on www.zcsazzurro.com . If it isn't, update to the latest version. If the errors still occur, contact technical support
ID148	RTCFault	RTC clock error	Internal inverter errors. Check whether the inverter is updated to the latest version found on www.zcsazzurro.com . If it isn't, update to the latest version. If the errors still occur, contact technical support
ID149	CommEEPROMFault	EEPROM communication board error	
ID150	FlashFault	FLASH communication board error	
ID153	SciCommLose(DC)	SCI communication error (DC)	
ID154	SciCommLose(AC)	SCI communication error (AC)	
ID155	SciCommLose(Fuse)	SCI communication error (fuse)	
ID156	SoftVerError	Incorrect software version	Check whether the inverter is updated to the latest version found on www.zcsazzurro.com . If it isn't, update to the latest version. If the errors still occur, contact technical support
ID157	BMSCommunicationFault Channel1	Lithium battery communication error channel 1	Make sure that the battery is compatible with the inverter. Check that the inverter channels are configured correctly, that the correct battery parameters have been set, and that both the power and communication cables have been connected correctly.
ID158	BMSCommunicationFault Channel 2	Lithium battery communication error channel 2	Make sure that the battery is compatible with the inverter. Check that the inverter channels are configured correctly, that the correct battery parameters have been set, and that both the power and communication cables have been connected correctly.
ID161	ForceShutdown	Forced shutdown	The inverter has undergone a forced shutdown, check that the ON/OFF

			switch has not been enabled in the advanced settings
ID162	RemoteShutdown	Remote shutdown	The inverter has undergone a forced remote shutdown
ID163	Drms0Shutdown	DRMs0 shutdown	The inverter has undergone a forced DRMs0 shutdown
ID165	RemoteDerating	Remote derating	The inverter has undergone a remote load derating
ID166	LogicInterfaceDerating	Logic interface derating	The inverter is loaded by running the logic interface.
ID167	AlarmAntiRefluxing	Anti-reflux derating	The inverter is programmed to prevent counter-current load sagging.
ID169	FanFault1	Fan1 error	Check whether fan 1 of the inverter is working properly
ID170	FanFault2	Fan2 error	Check whether fan 2 of the inverter is working properly
ID171	FanFault3	Fan3 error	Check whether fan 3 of the inverter is working properly
ID172	FanFault4	Fan4 error	Check whether fan 4 of the inverter is working properly
ID173	FanFault5	Fan5 error	Check whether fan 5 of the inverter is working properly
ID174	FanFault6	Fan6 error	Check whether fan 6 of the inverter is working properly
ID177	BMS OVP	BMS overvoltage alarm	Internal lithium battery error; turn off the inverter and battery, wait 5 minutes and then turn them on again. If the errors still occur, contact technical support
ID178	BMS UVP	BMS undervoltage alarm	
ID179	BMS OTP	BMS high temperature alarm	
ID180	BMS UTP	BMS low temperature alarm	
ID181	BMS OCP	BMS overload warning when charging and discharging	
ID182	BMS Short	BMS short-circuit alarm	

7. Uninstalling

7.1. Uninstallation steps

- Disconnect the inverter from the AC grid.
- Disconnect the DC switch (located on the battery or installed on the wall)
- Wait 5 minutes.
- Remove the DC connectors from the inverter.
- Remove the connectors for communication with the batteries and current sensors.
- Remove the AC terminals.
- Unscrew the fixing bolt of the bracket and remove the inverter from the wall.

7.2. Packaging

If possible, pack the product in its original packaging.

7.3. Storage

Store the inverter in a dry place where the ambient temperature is between -25 and +60°C.

7.4. Disposal

Zucchetti Centro Sistemi S.p.a. is not liable for the disposal of the equipment, or parts thereof, which does not take place according to the regulations and standards in force in the country of installation.



Where present, the symbol of the crossed-out wheeled bin indicates that the equipment, at the end of its useful life, must be disposed of separately from household waste.











This product must be handed over to the waste collection point in your local community for recycling.

For more information, please contact the waste collection authority in your country.

Inappropriate waste disposal could have negative effects on the environment and on human health due to potentially hazardous substances.

By cooperating in the proper disposal of this product, you contribute to the reuse, recycling and recovery of the product, and to the protection of our environment.

8. Monitoring systems

ZCS monitoring				
Product code	Product photo	APP monitoring	Portal monitoring	Possibility to send commands and to update the inverter remotely in case of technical support
ZSM-WIFI				
ZSM-ETH				
ZSM-4G				
Datalogger 4-10 Inverters				
Datalogger up to 31 Inverters				

8.1. External Wi-Fi adapter

8.1.1. Installation

Unlike the internal Wi-Fi card, the external adapter must be installed for all compatible inverters. However, the procedure is quicker and easier as there is no need to open the front cover of the inverter.

In order to monitor the inverter, the RS485 communication address must be set to 01 directly from the display.

Installation tools:

- Cross screwdriver
- External Wi-Fi adapter

- 1) Switch off the inverter following the procedure described in this manual.
- 2) Remove the cover for accessing the Wi-Fi connector on the bottom of the inverter by unscrewing the two cross-head screws (a), or by unscrewing the cover (b), as shown in the figure.

a)





(b)



Figure 214 - Pot for external Wi-Fi adapter

- 3) Insert the Wi-Fi adapter into the appropriate port, taking care to follow the direction of the connection and ensure correct contact between the two parts.

(a)



(b)





Figure 215 - Inserting and securing the external Wi-Fi adapter

- 4) Switch on the inverter by following the procedure described in the manual.

8.1.2. Configuration

Configuration of the Wi-Fi adapter requires the presence of a Wi-Fi network near the inverter in order to achieve stable transmission of data from the inverter adapter to the Wi-Fi modem.



Tools required for configuration:

- Smartphone, PC or tablet

Go to front of the inverter and search for the Wi-Fi network using a smartphone, PC or tablet, making sure that the signal from the home Wi-Fi network reaches the place where the inverter is installed.

If the Wi-Fi signal is present at the location where the inverter is installed, the configuration procedure can begin.

If the Wi-Fi signal does not reach the inverter, a system must be installed to amplify the signal and bring it to the installation location.

- 1) Activate the search for Wi-Fi networks on your phone or PC in order to display all the networks visible from your device.



Figure 216 - Wi-Fi network search on iOS smartphone (left) and Android (right)

Note: Disconnect from any Wi-Fi networks to which you are connected by removing automatic access.



Figure 217 – Disabling automatic reconnection to a network

- 2) Connect to a Wi-Fi network generated by the inverter's Wi-Fi adapter (i.e. AP_*****, where ***** indicates the serial number of the Wi-Fi adapter shown on the label of the device), which operates as an Access Point.




Figure 218 – Connection to Access Point of the Wi-Fi adapter on iOS smartphone (left) and Android smartphone (right)

- 3) If you are using a second-generation Wi-Fi adapter, you will be prompted for a password to connect to the inverter's Wi-Fi network. Use the password found on the box or on the Wi-Fi adapter.





Figure 219 – Password of external Wi-Fi adapter

Note: To ensure that the adapter is connected to the PC or smartphone during the configuration procedure, enable automatic reconnection of the AP_***** network.




Figure 220 – Password entry prompt

Note: the Access Point is not able to provide internet access; confirm to maintain the Wi-Fi connection, even if internet is not available





Figure 221 – Screen showing that the Internet cannot be accessed

- 4) Open a browser (Google Chrome, Safari, Firefox) and enter the IP address 10.10.100.254 in the address bar at the top of the screen.
In the box that appears, enter “admin” as both Username and Password.




Figure 222 – Screen for accessing the web server to configure the Wi-Fi adapter

- 5) The status screen will open, showing the logger information such as the serial number and firmware version.

Check that the Inverter Information fields are filled in with the inverter information.

The language of the page can be changed using the command in the top right-hand corner.



中文 | English

Status																																															
Wizard																																															
Quick Set																																															
Advanced																																															
Upgrade																																															
Restart																																															
Reset																																															
	<div style="border: 2px solid red; padding: 5px;"> <p>- Inverter information</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Inverter serial number</td><td>ZH1ES160J3E488</td></tr> <tr><td>Firmware version (main)</td><td>V210</td></tr> <tr><td>Firmware version (slave)</td><td>---</td></tr> </table> </div> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr><td>Inverter model</td><td>ZH1ES160</td></tr> <tr><td>Rated power</td><td>--- W</td></tr> <tr><td>Current power</td><td>--- W</td></tr> <tr><td>Yield today</td><td>11.2 kWh</td></tr> <tr><td>Total yield</td><td>9696.0 kWh</td></tr> <tr><td>Alerts</td><td>F12F14</td></tr> <tr><td>Last updated</td><td>0</td></tr> </table> <p>- Device information</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr><td>Device serial number</td><td>1701917282</td></tr> <tr><td>Firmware version</td><td>LSW3_14_FFFF_1.0.00</td></tr> <tr><td>Wireless AP mode</td><td>Enable</td></tr> <tr><td> SSID</td><td>AP_1701917282</td></tr> <tr><td> IP address</td><td>10.10.100.254</td></tr> <tr><td> MAC address</td><td>98:d8:63:54:0a:87</td></tr> <tr><td>Wireless STA mode</td><td>Enable</td></tr> <tr><td> Router SSID</td><td>AP_SOLAR_PORTAL_M2M_20120615</td></tr> <tr><td> Signal Quality</td><td>0%</td></tr> <tr><td> IP address</td><td>0.0.0.0</td></tr> <tr><td> MAC address</td><td>98:d8:63:54:0a:86</td></tr> </table> <p>- Remote server information</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr><td>Remote server A</td><td>Not connected</td></tr> <tr><td>Remote server B</td><td>Not connected</td></tr> </table>	Inverter serial number	ZH1ES160J3E488	Firmware version (main)	V210	Firmware version (slave)	---	Inverter model	ZH1ES160	Rated power	--- W	Current power	--- W	Yield today	11.2 kWh	Total yield	9696.0 kWh	Alerts	F12F14	Last updated	0	Device serial number	1701917282	Firmware version	LSW3_14_FFFF_1.0.00	Wireless AP mode	Enable	SSID	AP_1701917282	IP address	10.10.100.254	MAC address	98:d8:63:54:0a:87	Wireless STA mode	Enable	Router SSID	AP_SOLAR_PORTAL_M2M_20120615	Signal Quality	0%	IP address	0.0.0.0	MAC address	98:d8:63:54:0a:86	Remote server A	Not connected	Remote server B	Not connected
Inverter serial number	ZH1ES160J3E488																																														
Firmware version (main)	V210																																														
Firmware version (slave)	---																																														
Inverter model	ZH1ES160																																														
Rated power	--- W																																														
Current power	--- W																																														
Yield today	11.2 kWh																																														
Total yield	9696.0 kWh																																														
Alerts	F12F14																																														
Last updated	0																																														
Device serial number	1701917282																																														
Firmware version	LSW3_14_FFFF_1.0.00																																														
Wireless AP mode	Enable																																														
SSID	AP_1701917282																																														
IP address	10.10.100.254																																														
MAC address	98:d8:63:54:0a:87																																														
Wireless STA mode	Enable																																														
Router SSID	AP_SOLAR_PORTAL_M2M_20120615																																														
Signal Quality	0%																																														
IP address	0.0.0.0																																														
MAC address	98:d8:63:54:0a:86																																														
Remote server A	Not connected																																														
Remote server B	Not connected																																														

Help

The device can be used as a wireless access point (AP mode) to facilitate users to configure the device, or it can also be used as a wireless information terminal (STA mode) to connect the remote server via wireless router.

Status of remote server

◆Not connected: Connection to server failed last time.
If under such status, please check the issues as follows:
(1) check the device information to see whether IP address is obtained or not;
(2) check if the router is connected to internet or not;
(3) check if a firewall is set on the router or not;

◆Connected: Connection to server successful last time;

◆Unknown: No connection to server. Please check again in 5 minutes.

Figure 223 – Status Screen

- 6) Click on the Wizard setup button in the left-hand column.
- 7) In the new screen that opens, select the Wi-Fi network to which you want to connect the Wi-Fi adapter, making sure that the Received Signal Strength Indicator (RSSI) is greater than 30%. If the network is not visible, press the Refresh button.
Note: check that the signal strength is greater than 30%, if not, bring the router closer or install a repeater or signal amplifier.
Click Next.

Please select your current wireless network:

Site Survey

SSID	BSSID	RSSI	Channel
<input checked="" type="radio"/> iPhone di Giacomo	EE:25:EF:6C:31:18	100	6
<input type="radio"/> ZcsWiFi	FE:EC:DA:1D:C3:9	86	1
<input type="radio"/> ZcsHotSpot	FC:EC:DA:1D:C3:9	86	1
<input type="radio"/> WLAN	E:EC:DA:1D:C3:9	86	1
<input type="radio"/> ZcsHotSpot	FC:EC:DA:1D:C8:A3	57	11
<input type="radio"/> WLAN	E:EC:DA:1D:C8:A3	57	11
<input type="radio"/> ZcsWiFi	FE:EC:DA:1D:C8:A3	54	11
<input type="radio"/> WLAN	E:EC:DA:1D:C8:8B	45	1
<input type="radio"/> ZcsWiFi	FE:EC:DA:1D:C8:8B	37	1
<input type="radio"/> ZcsHotSpot	FC:EC:DA:1D:C8:8B	35	1

★Note: When RSSI of the selected WiFi network is lower than 15%, the connection may be unstable, please select other available network or shorten the distance between the device and router.

Refresh

Add wireless network manually:

Network name (SSID)
(Note: case sensitive)

Encryption method

Encryption algorithm

Next

1 2 3 4

Figure 224 – Screen for selecting the available wireless network (1)

- 8) Enter the password of the Wi-Fi network (Wi-Fi modem), clicking on Show Password to make sure it is correct; the password should not contain special characters (&, #, %) and spaces. Note: During this step, the system is not able to ensure that the password entered is the one actually requested by the modem; therefore, make sure you enter the correct password. Also check that the box below the password is set to Enable.



Please fill in the following information:

Password (8-64 bytes)
(Note: case sensitive)
 Show Password

Obtain an IP address automatically ▾

IP address

Subnet mask

Gateway address

DNS server address

1 2 3 4

Figure 225 - Screen for entering the password of the wireless network (2)

- 9) Click “Next” again **without ticking** any of the options relating to the adapter security.

Enhance Security

You can enhance your system security by choosing the following methods

- Hide AP
- Change the encryption mode for AP
- Change the user name and password for Web server

1 2 3 4

Figure 226 - Screen for setting the security options (3)



10) Click “OK”.

Setting complete!

Click OK, the settings will take effect and the system will restart immediately.

If you leave this interface without clicking OK, the settings will be ineffective.



Figure 227 - Final configuration screen (4)

- 11) At this point, if the adapter configuration was successful, the last configuration screen will appear, and the telephone or PC will unpair from the inverter’s Wi-Fi network.
- 12) Manually close the web page with the Close key on the PC or remove it from the background of the telephone.

Setting complete! Please close this page manually!

Please login our management portal to monitor and manage your PV system.(Please register an account if you do not have one.)

To re-login the configuration interface, please make sure that your computer or smart phone

Web Ver:1.0.24

Figure 228 - Successful configuration screen



8.1.3. Check

To check that the network has been configured correctly, connect to it again and enter the status page.
Check the following information:

- a. Wireless STA mode
 - i. Router SSID > Router name
 - ii. Signal Quality > other than 0%
 - iii. IP address > other than 0.0.0.0
- b. Check Remote server information
 - i. Remote server A > Connected

Wireless STA mode	Enable
Router SSID	iPhone di Giacomo
Signal Quality	0%
IP address	0.0.0.0
MAC address	98:d8:63:54:0a:86
- Remote server information	
Remote server A	Not connected

Figure 229 – Status Screen

Status of LEDs present on the adapter

- 1) Initial status:
 - NET (left LED): off
 - COM (central LED): steady on
 - READY (right LED): flashing on



Figure 230 – Initial status of LEDs

- 2) Final status:
 - NET (left LED): steady on



COM (central LED): steady on
READY (right LED): flashing on



Figure 231 - Final status of LEDs

If the NET LED does not light up or if the Remote Server A option in the Status page still shows “Not Connected”, the configuration was not successful, i.e. the wrong router password was entered or the device was disconnected during connection.

It is necessary to reset the adapter:

- Press the reset button for 10 seconds and release
- After a few seconds, the LEDs will turn off and READY will start to flash quickly
- The adapter has now returned to its initial state. At this point, the configuration procedure can be repeated again.

The adapter can only be reset when the inverter is switched on.



Figure 232 – Reset button on the Wi-Fi adapter

8.1.4. Troubleshooting

Status of LEDs present on the adapter

- 1) Irregular communication with inverter



- NET (left LED): steady on
- COM (central LED): off
- READY (right LED): flashing on



Figure 233 - Irregular communication status between inverter and Wi-Fi

- Check the Modbus address set on the inverter:
Enter the main menu with the ESC key (first key on the left), go to System Info and press ENTER to enter the submenu. Scroll down to the Modbus address parameter and make sure it is set to 01 (and in any case, other than 00).

If the value is not 01, go to “Settings” (basic settings for hybrid inverters) and enter the Modbus Address menu where the 01 value can be set.

- Check that the Wi-Fi adapter is correctly and securely connected to the inverter, making sure to tighten the two cross-head screws provided.
- Check that the Wi-Fi symbol is present in the top right-hand corner of the inverter's display (steady or flashing).



Figure 234 - Icons on the display of LITE single-phase inverters (left) and three-phase or hybrid inverters (right)

- Restart the adapter:
 - Press the reset button for 5 seconds and release
 - After a few seconds, the LEDs will turn off and will start to flash quickly
 - The adapter will now be reset without losing the configuration with the router

2) Irregular communication with remote server

- NET (left LED): off

- COM (central LED): on
- READY (right LED): flashing on



Figure 235 – Irregular communication status between Wi-Fi and remote server

- Check that the configuration procedure has been carried out correctly and that the correct network password has been entered.
- When searching for the Wi-Fi network using a smartphone or PC, make sure that the Wi-Fi signal is strong enough (a minimum RSSI signal strength of 30% is required during configuration). If necessary, increase it by using a network extender or a router dedicated to inverter monitoring.
- Check that the router has access to the network and that the connection is stable; use a PC or smartphone to check that it is possible to access the Internet
- Check that port 80 of the router is open and enabled to send data
- Reset the adapter as described in the previous section

If, at the end of the previous checks and subsequent configuration, Remote server A is still “Not Connected” or the NET LED is off, there may be a transmission problem at the home network level and, more specifically, that data between the router and server is not being transmitted correctly. In this case, it is advisable to carry out checks at the router level in order to ensure that there are no obstructions on the output of data packets to our server.

To make sure that the problem lies in the home router and to exclude problems with the Wi-Fi adapter, configure the adapter using the Wi-Fi hotspot function on your smartphone as a reference wireless network.

• Using an Android mobile phone as a modem

- a) Check that the 3G/LTE connection is active on your smartphone. Go to the Settings menu of the operating system (the gear icon on the screen with a list of all the apps installed on the phone), select “Other” from the Wireless and networks menu and make sure that the Network type is set to 3G/4G/5G.
- b) In the Android settings menu, go to Wireless & networks > Other. Select Mobile Hotspot/Tethering, and then enable the Wi-Fi mobile hotspot option; wait a few seconds

for the wireless network to be created. To change the name of the wireless network (SSID) or your password, select Configure Wi-Fi hotspot.




Figure 236 – Configuration of an Android smartphone as a hotspot router

- **Using an iPhone as a modem**

- In order to share the iPhone connection, check that the 3G/LTE network is active by going to Settings > Mobile Phone, and making sure that the “Voice and data” option is set to 5G, 4G or 3G. To enter the iOS settings menu, click the grey gear icon on the home screen of your phone.
- Go to the Settings menu > Personal Hotspot and turn on the Personal Hotspot option. The hotspot is now enabled. To change the password of the Wi-Fi network, select Wi-Fi password from the personal hotspot menu.






Figure 237 - Configuration of an iOS smartphone as a hotspot router

At this point, it is necessary to re-configure the Wi-Fi adapter using a PC or smartphone other than the one used as a modem.

During this procedure, when asked to select the Wi-Fi network, choose the one activated by the smartphone and then enter the password associated with it (which can be changed from the personal hotspot settings). If the word "Connected" appears next to "Remote Server A" at the end of configuration, then the problem is with the home router.

It is therefore advisable to check the brand and model of the home router that you are trying to connect to the Wi-Fi adapter; some router brands may have closed communication ports. In this case, contact the customer service of the router's manufacturer and ask them to open port 80 (direct from the network to external users).



8.2. Ethernet adapter

8.2.1. Installation

All inverters compatible with the adapter must be installed. However, the procedure is quicker and easier as there is no need to open the front cover of the inverter. Correct operation of the device requires a modem to be correctly connected to the network and operational in order to achieve stable data transmission from the inverter to the server.

In order to monitor the inverter, the RS485 communication address must be set to 01 directly from the display.

Installation tools:

- Cross screwdriver
- Ethernet adapter
- Shielded network (Cat. 5 or Cat. 6) crimped with RJ45 connectors

- 1) Switch off the inverter following the procedure described in this manual.
- 2) Remove the cover for accessing the Wi-Fi/Eth connector on the bottom of the inverter by unscrewing the two cross-head screws (a), or by unscrewing the cover (b), depending on the model, the inverter as shown in figure.

(a)



(b)



Figure 238 - Slot for the Ethernet adapter

- 3) Remove the ring nut and the waterproof cable gland from the adapter to allow the network cable to pass through. Then insert the network cable network into the appropriate slot inside the card and tighten the ring nut and cable gland to ensure a stable connection.






Figure 239 - Inserting the network cable inside the device

- 4) Insert the Ethernet adapter into the appropriate slot, taking care to follow the direction of the insertion and ensure correct contact between the two parts.




Figure 240 - Inserting and securing the Ethernet adapter

- 5) Connect the other end of the network cable to the ETH output (or equivalent) of the modem or a suitable data transmission device.






Figure 241 – Connecting the network cable to the modem

- 6) Switch on the inverter by following the procedure described in the manual.
- 7) Unlike Wi-Fi cards, the Ethernet device does not need to be configured and starts transmitting data shortly after the inverter has been switched on.

8.2.2.Check

Wait two minutes after installing the adapter, and check the status of the LEDs on the device.

Status of LEDs present on the adapter

- 1) Initial status:
 - NET (left LED): off
 - COM (central LED): steady on
 - SER (right LED): flashing on



Figure 242 – Initial status of LEDs





- 2) Final status:
NET (left LED): steady on
COM (central LED): steady on
SER (right LED): flashing on



Figure 243 - Final status of LEDs

8.2.3. Troubleshooting

Status of LEDs present on the adapter

- 1) Irregular communication with inverter
- NET (left LED): steady on
 - COM (central LED): off
 - SER (right LED): flashing on



Figure 244 - Irregular communication status between inverter and adapter

- Check the Modbus address set on the inverter:
Enter the main menu with the ESC key (first key on the left), go to System Info and press ENTER to enter the submenu. Scroll down to the Modbus address parameter and make sure it is set to 01 (and in any case, other than 00).



If the value is not 01, go to “Settings” (basic settings for hybrid inverters) and enter the Modbus Address menu where the 01 value can be set.

- Check that the Ethernet adapter is correctly and securely connected to the inverter, making sure to tighten the two cross-head screws provided. Check that the network cable is correctly inserted into the device and modem, and that the RJ45 connector is correctly crimped.

2) Irregular communication with remote server

- NET (left LED): off
- COM (central LED): on
- SER (right LED): flashing on



Figure 245 – Irregular communication status between adapter and remote server

- Check that the router has access to the network and that the connection is stable; use a PC to check that it is possible to access the Internet

Check that port 80 of the router is open and enabled to send data.

It is advisable to check the brand and model of the home router you are trying to connect to the Ethernet adapter. Some router brands may have closed communication ports. In this case, contact the customer service of the router’s manufacturer and ask them to open port 80 (direct from the network to external users).

8.3. 4G adapter

The ZCS 4G adapters are sold with a virtual SIM integrated into the device with data traffic fee included for 10 years, which is adequate for the proper transmission of data to monitor the inverter.

In order to monitor the inverter, the RS485 communication address must be set to 01 directly from the display.

8.3.1. Installation

All inverters compatible with the adapter must be installed. However, the procedure is quicker and easier as there is no need to open the front cover of the inverter.

Installation tools:

- Cross screwdriver
- 4G adapter

- 1) Switch off the inverter following the procedure described in this manual.
- 2) Remove the cover for accessing the Wi-Fi/GPRS connector on the bottom of the inverter by unscrewing the two cross-head screws (a), or by unscrewing the cover (b), depending on the inverter model, as shown in the figure.



Figure 246 - Slot for the 4G adapter

- 3) Insert the 4G adapter into the appropriate slot, taking care to follow the direction of the insertion and ensure correct contact between the two parts. Secure the 4G adapter by tightening the two screws inside the package.






Figure 247 - Inserting and securing the 4G adapter

- 4) Switch on the inverter by following the procedure described in the manual.
- 5) Unlike Wi-Fi monitoring cards, the 4G device does not need to be configured and starts transmitting data shortly after the inverter has been switched on.

8.3.2.Check

After installing the adapter, within the next 3 minutes check the status of the LEDs on the device to ensure that the device is configured correctly.

Status of LEDs present on the adapter

- 1) Initial status:
 - NET (left LED): off
 - COM (central LED): flashing on
 - SER (right LED): flashing on





Figure 248 - Initial status of LEDs

2) Registration:

- NET (left LED): flashes rapidly for about 50 seconds; the registration process takes about 30 seconds
- COM (central LED): flashes rapidly 3 times after 50 seconds

3) Final status (approx. 150 seconds after the inverter has started):

- NET (left LED): flashing on (off and on at equal intervals)
- COM (central LED): steady on
- SER (right LED): steady on



Figure 249 - Final status of LEDs

Status of LEDs present on the adapter

1) Irregular communication with inverter

- NET (left LED): on
- COM (central LED): off
- SER (right LED): on





Figure 250 - Irregular communication status between inverter and adapter

- Check the Modbus address set on the inverter:
Enter the main menu with the ESC key (first key on the left), go to System Info and press ENTER to enter the submenu. Scroll down to the Modbus address parameter and make sure it is set to 01 (and in any case, other than 00).

If the value is not 01, go to “Settings” (basic settings for hybrid inverters) and enter the Modbus Address menu where the 01 value can be set.

- Check that the 4G adapter is correctly and securely connected to the inverter, making sure to tighten the two cross-head screws provided.

2) Irregular communication with remote server:

- NET (left LED): flashing on
- COM (central LED): on
- SER (right LED): flashing on



Figure 251 - Irregular communication status between adapter and remote server




















- Check that the 4G signal is present in the installation location (the adapter uses the Vodafone network for 4G transmission. If this network is not present or the signal is weak, the SIM will use a different network or will limit the data transmission speed). Ensure that the installation location is suitable for 4G signal transmission and that there are no obstacles that could affect data transmission.
- Check the status of the 4G adapter and that there are no external signs of wear or damage.



8.4. Datalogger

8.4.1. Preliminary notes on how to configure the datalogger

ZCS Azzurro inverters can be monitored via a datalogger connected to a Wi-Fi network present at the place of installation or via an Ethernet cable connected to a modem.

ZCS monitoring				
Product code	Product photo	APP monitoring	Portal monitoring	Possibility to send commands and to update the inverter remotely in case of technical support
ZSM-WIFI				
ZSM-ETH				
ZSM-4G				
Datalogger 4-10 Inverters				
Datalogger up to 31 Inverters				



The inverters are connected in a daisy chain to the datalogger via a RS485 serial line.

- Datalogger up to 4 inverters (code ZSM-DATALOG-04): allows to monitor up to 4 inverters.
It can be connected to the network via an Ethernet or Wi-Fi network.
- Datalogger up to 10 inverters (code ZSM-DATALOG-10): allows to monitor up to 10 inverters.
It can be connected to the network via an Ethernet or Wi-Fi network.



Figure 252 – Diagram for connecting the ZSM-DATALOG-04 / ZSM-DATALOG-10 datalogger

- Datalogger up to 31 inverters (code ZSM-RMS001/M200): allows to monitor up to 31 inverters or a system with a maximum installed power of 200kW.
It can be connected to the network via an Ethernet cable.
- Datalogger up to 31 inverters (code ZSM-RMS001/M1000): allows to monitor a maximum of 31 inverters or a system with a maximum installed power of 1000kW.
It can be connected to the network via an Ethernet cable.



Figure 253 – Diagram for the functioning of the ZSM-RMS001/ M200 / ZSM-RMS001/M1000 datalogger

All these devices carry out the same function, i.e. they transmit data from the inverters to a web server to allow remote monitoring of the system either via the “Azzurro System” app or the [“www.zcsazzurroportal.com”](http://www.zcsazzurroportal.com) website.

All the Azzurro ZCS inverters can be monitored using the datalogger; different models or families of inverters can also be monitored.

8.4.2. Electrical connections and configuration

All the Azzurro ZCS inverters have at least one RS485 connection point.


The connections can be made via the green terminal block or via the RJ45 plug inside the inverter.

Use positive and negative conductors. There is no need to use a conductor for the GND. This applies to both the terminal block and the plug.

For the creation of the serial line use a certified cable for RS485 2x0,5mm² shielded. Connect the shield to the ground only on 1 of the 2 sides (preferably inverter side).

In case of more inverters continue the shielding between pieces of cables (COM Inverter port).

- 1) In case of three-phase inverter it is possible to use a RS485 certified cable properly crimped with RJ45 connector:
 - a. Place the blue cable in position 4 of the RJ45 connector and the white-blue cable in position 5 of the RJ45 connector, as shown in the figure below.
 - b. Insert the connector into the 485-OUT terminal.
 - c. If there is more than one three-phase inverter, insert another connector in the 485-IN terminal to connect to the 485-OUT input of the next inverter.



RJ 45	Colore	Monofase	Trifase
4	Blu	TX +	485 A
5	Bianco-Blu	TX -	485 B

Figure 254 – Pin out for connecting the RJ45 connector

2) Daisy chain

- a. Insert the blue cable into input A1 and the white-blue cable into input B1.
- b. If there is more than one three-phase inverter, insert a blue cable into input A2 and a white-blue cable into input B2 and connect them to the respective A1 and B1 inputs of the next inverter.

Some inverters have both an RS485 terminal block and RJ45 plugs. This is shown in detail in the figure below.




Figure 255 - Tightening the network cable to the RS485 terminal block




Figure 256 - Connecting the serial line via the RS485 terminal block and via the RJ45 plug

For 3PH HYD5000-HYD20000-ZSS three-phase hybrid inverters, use only one positive and one negative of those shown in the figure below.





Figure 257 - Connecting the serial line via the communication connector for 3PH HYD5000-HYD20000-ZSS inverters




For 3000-6000 TLM-V3 photovoltaic inverters and HYD 3PH 5000-20000 ZSS three-phase hybrid inverters, use only one positive and one negative of those shown in the figure below.



- Pin 1 - 2 / RS458+
- Pin 3 - 4 / RS485-

Figure 258 - Connecting the serial line via the communication connector for 1PH 3000- 6000 TLM-V3 inverters

For 1PH HYD3000-HYD6000-ZSS-HP single-phase hybrid inverters, use only one positive and one negative of those shown in the figure below



- Pin 3 - 5 / RS485 +
- Pin 4 - 6 / RS485 -

Figure 259 - Connecting the serial line via the communication connector for 3PH HYD5000-HYD20000-ZSS inverters

- a. Position the dip switches of the last inverter in the daisy chain connection as shown in the figure below to activate the 120 Ohm resistor and close the communication chain. If there are no switches, physically connect a 120 Ohm resistor to terminate the bus.






Figure 260 – Positioning of the dip switches to connect the isolation resistor

- 3) Check that the RS485 icon is shown on the display of all the inverters, which indicates that the inverters are actually connected via the serial line. If this symbol does not appear, check that the connection is correct, as indicated in this guide.




Figure 261 – RS485 symbol on the inverter display

- 4) Set a sequential Modbus address on each inverter connected:
 - a. Enter the “Settings” menu.
 - b. Scroll to the submenu “Modbus Address.”
 - c. Change the digits and set an increasing address on each inverter, starting from 01 (first inverter) to the last inverter connected. The Modbus address will be shown on the display of the inverter alongside the RS485 symbol. There should be no inverters with the same Modbus address.

8.4.3.ZSM-DATALOG-04 AND ZSM-DATALOG-10 Devices

The initial status of the LEDs on the datalogger will be:

- POWER steady on
- 485 steady on
- LINK off
- STATUS steady on

8.4.4.WI-FI CONFIGURATION

To configure the datalogger via Wi-Fi, please refer to the chapter on monitoring systems, as the configuration is similar to that of any type of Wi-Fi adapter.

8.4.5. Ethernet configuration

- 1) Insert the RJ45 connector of the Ethernet cable in the ETHERNET input of the datalogger.




Figure 262 – Ethernet cable connected to the datalogger

- 2) Connect the other end of the Ethernet cable to the ETH output (or equivalent) of the modem or a suitable data transmission device.
- 3) Activate the search for Wi-Fi networks on your phone or PC in order to display all the networks visible from your device.



Figure 263 - Wi-Fi network search on iOS (left) and Android (right) smartphone

Note: Disconnect from any Wi-Fi networks to which you are connected by removing automatic access.





Figure 264 - Disabling automatic reconnection to a network

- 4) Connect to a Wi-Fi network generated by the datalogger (i.e. AP_*****, where ***** indicates the serial number of the datalogger shown on the label of the device), which operates as an Access Point.
- 5) Note: To ensure that the datalogger is connected to the PC or smartphone during the configuration procedure, enable automatic reconnection of the AP_***** network.




Figure 265- Password entry prompt

Note: the Access Point is not able to provide internet access; confirm to maintain the Wi-Fi connection, even if internet is not available.





Figure 266- Screen showing that the Internet cannot be accessed

- 6) Open a browser (Google Chrome, Safari, Firefox) and enter the IP address 10.10.100.254 in the address bar at the top of the screen. In the box that appears, enter “admin” as both Username and Password.




Figure 267 - Screen for accessing the web server to configure the datalogger

- 7) The status screen will open, showing the datalogger information such as serial number and firmware version.

Check that the fields relating to the Inverter Information are filled in with the information of all the inverters connected.






Figure 268 – Status Screen

- 8) Click on the Wizard setup button in the left-hand column.
- 9) Now click on the Start button to start the configuration wizard.

Dear user:

Thank you for choosing our device.
Next, you can follow the setup wizard to complete the network setting step by step; or you can select the left menu for detailed settings.

★Note: Before setting, please make sure that your wireless or cable network is working.

Start

1 2 3 4 5 6 7

Figure 269 – Screen for starting (1) the Setup Wizard

- 10) Check the “Cable Connection” option and then click “Next.”






Figure 270 - Screen for selecting connection via network cable

11) Make sure that the “Enable” option is selected to automatically obtain the IP address from your router, then click Next.

Please fill in the following information:

Obtain an IP address automatically	Enable ▾
IP address	0.0.0.0
Subnet mask	0.0.0.0
Gateway address	0.0.0.0
DNS server address	



Figure 271 - Screen for automatically obtaining the IP address (5)

12) Click on Next without making any changes.



Enhance Security

You can enhance your system security by choosing the following methods

Hide AP

Change the encryption mode for AP

Change the user name and password for Web server

Back

Next

1 2 3 4 5 6 7

Figure 272 - Screen for setting the security options (6)

13) Complete the configuration procedure by clicking OK, as shown in the following screen.

Configuration completed!

Click OK, the settings will take effect and the system will restart immediately.

If you leave this interface without clicking OK, the settings will be ineffective.

Back

OK

1 2 3 4 5 6 7

Figure 273 - Final configuration screen (7)

14) If the configuration procedure is successful, the following screen will appear.

If this screen does not appear, try refreshing the browser page.

The screen will prompt you to manually close the page; close the page from the background of your phone or from the close button on your PC.




Figure 274 – Successful configuration screen

8.4.6. Checking that the datalogger has been configured correctly

Wait two minutes after completing the configuration of the device. First of all, check that the LINK LED on the device is on and steady.



Figure 275 – LED indicating the correct configuration of the datalogger

Enter the IP address 10.10.100.254 again, and the login credentials (“admin” for both username and password). Once logged in again, the Status screen will appear, where the following information can be checked:

- Check Wireless STA mode (if the datalogger has been configured via Wi-Fi)
 - Router SSID > Router name

- Signal Quality > other than 0%
- IP address > other than 0.0.0.0
- Check Cable mode (if the datalogger has been configured via Ethernet cable)
 - IP address > other than 0.0.0.0
- Check Remote server information
 - Remote server A > Pingable

Device information

Device serial number	508263482
Firmware version	H4.01.51MW.2.01W1.0.74(2019-03-143-D)
Wireless AP mode	Enable
SSID	AP_508263482
IP address	10.10.100.254
MAC address	BC:54:F9:F6:B9:74
Wireless STA mode	Enable
Router SSID	iPhone di Giacomo
Signal quality	100%
IP address	172.20.10.10
MAC address	BC:54:F9:F6:B9:75
Cable mode	Disable
IP address	
MAC address	

Connected Inverter

Type	ZCS
Number	1
Inverter serial number	ZA1ES111G8R273 ▾
Firmware version (main)	V550
Firmware version (slave)	---
Inverter model	ZA1ES111
Rated power	1 00 W
Current power	0 W
Yield today	0 kWh
Total yield	0 kWh
Alerts	F12F14
Last updated	0 min ago

Remote server information

Remote server A	Pingable
-----------------	----------

Figure 276 – Main screen of status and checking of correct configuration

Cable mode	Enable
IP address	192.168.0.177
MAC address	BC:54:F9:F6:B9:77

Figure 277 - Main screen of status and checking of correct configuration



If the Remote Server A item in the Status page is still “Unpingable”, the configuration was not successful, i.e. the incorrect router password was entered or the device was disconnected during connection.

It is necessary to reset the device:

- Select the Reset button in the left-hand column
- Press the OK button to confirm
- Close the web page and enter the Status page again. At this point, the configuration procedure can be repeated again.




Figure 278 – Reset screen



8.4.7.ZSM-RMS001/M200 and ZSM-RMS001/M1000 Devices

8.4.7.1. Mechanical description and Datalogger interface

Mechanical Dimensions: 127mm x 134 x 52 mm

Protection rating: IP20

The usable ports are indicated below.




Figure 279: Back of Datalogger

8.4.7.2. Connecting the Datalogger to the inverters

A serial communication via RS485 cable is provided for connecting to the inverters.

The GND cable does not need to be connected to the inverters. Follow the connections as shown in the table below.

Datalogger SIDE	BUS Signal	SENSOR SIDE (ZSM-IRR-TEMP-LM2)	Inverter SIDE
Terminal D+	+	Terminal RS485 +/B	Terminal +Tx
Terminal D-	-	Terminal RS485 -/A	Terminal -Tx

Table 21: Connecting the Datalogger to the inverters

8.4.7.3. Internet connection via Ethernet cable

In order to display the data measured and processed by the Datalogger in the portal, it is necessary to connect to the internet via LAN cable and open the following router ports:

- VPN ports: 22 and 1194
- HTTP ports: 80
- DB ports: 3050
- FTP ports: 20 and 21

The local network of the device is configured for DHCP, and there is no need to activate any communication port on the router. If you want to set a fixed network address, this must be provided at the time of ordering together with the gateway address.

8.4.7.4. Connecting the power supply and battery pack to the Datalogger

Once the RS485 Half Duplex cable has been connected, the Datalogger must be powered by connecting the power supply unit (supplied with the datalogger) to the MAIN PWR input (12V DC - 1A).

In order to prevent possible voltage drops and/or power failures, it is recommended to also connect the battery pack, which is supplied with the datalogger. The battery pack should be connected to the +V_{bat} and GND inputs of the BATT PWR connector, positive and negative respectively (i.e. red to the +V_{bat} input and black to the GND input).

The battery pack (ZSM-UPS-001) can be purchased separately.

8.4.7.5. Connecting the LM2-485 PRO cell irradiation and temperature sensor to the datalogger

For proper installation, both the sensor signal and power cables must be connected.





In particular, the sensor of the signal cables must be connected in a daisy chain configuration to the remaining devices on the RS485 bus, as shown in the table below.

Datalogger SIDE	BUS Signal	SENSOR SIDE (ZSM-IRR-TEMP-LM2)	Inverter SIDE
Terminal D+	+	Terminal RS485+/ B	Terminal +Tx
Terminal D-	-	Terminal RS485-/ A	Terminal -Tx

To supply power to the sensor, the datalogger can be directly connected to the mains power, as shown in the table below, or connected to an external +12Vdc power supply.

Datalogger SIDE	SENSOR SIDE
Terminal V1 (12Vdc output voltage)	Terminal RED +12V
Terminal GND (GND/RTN)	Terminal BLACK 0V
Terminal V2 (12Vdc driveable voltage)	

Table 22: Electrical connection of the sensor to the datalogger (power supply)


A stable communication in terms of signal and power supply, up to 200m, is guaranteed by using the RS485 cable, type Te.Co G83/15166, 2x2x0/22, 1x0/22, /.

For longer distances, a connection to the signal side of the datalogger is recommended, and a connection to the +12V power supply via an external power supply unit.




8.4.8. Configuring the Datalogger


Connect to the website dlconfig.it and login by entering the temporary credentials: Username = admin and Password = admin.



In the screen that opens, enter the serial number (S/N) of the datalogger to be configured and click "SEARCH".



In the configuration page, you can search for any devices connected to the datalogger (inverter, meter or sensors) by clicking the + button, as shown in the figure.



A window will open where you can search for each type of device connected to the Datalogger, after indicating the range of addresses associated with the relative devices.



Scan
Command the datalogger to perform a discovery. Find and confirm new and old devices.

Device Type

- Sensor
- Meter
- Inverter

Vendor

Protocol

CANCEL NEXT

If a meter is one of the devices connected to the Datalogger, select the type of Meter/Datalogger communication interface and the relative communication protocol.

Scan
Command the datalogger to perform a discovery. Find and confirm new and old devices.

Device Type
Meter

Vendor
Algodue

Interface

- RS-485
- TCP

Protocol

CANCEL NEXT

Scan
Command the datalogger to perform a discovery. Find and confirm new and old devices.

Device Type
Meter

Vendor
Algodue

Interface
RS-485

Protocol

- ASCII
- RTU

CANCEL NEXT

Once this operation has been completed, update the new configuration by clicking “Confirm,” which will allow you to register the devices associated with the datalogger.

Confirm changes

State

Confirming new **1**

Total now **1**

CONFIRM




From this moment, the datalogger is correctly configured (all devices must be in the “saved” status) and therefore a new installation can be created on the ZCS Azzurro portal for associating the datalogger and the devices connected to it.


Configuration								Scan for devices
Create and review your datalogger configuration. Use the "plus" button to scan for devices.								+
Device Type	Direction	Vendor	Interface	Protocol	Serial number	Slave Id	Status	
Inverter		ZCS	RS-485	RTU	ZM1ES030JC4258	1	Saved	

8.4.8.1. Configuring the Datalogger on the ZCS Azzurro portal

Access the ZCS Azzurro portal (<https://www.zcsazzurroportal.com>). For new users, click “Sign up now” to register on the portal by entering your email, username and password. After logging into the portal, click “Configuration Panel”, and then select the option “Create field with Datalogger.” The “Create New Field” operation will be possible only if the user’s privileges allow acquiring new fields (at the time of registration the limit will be equal to 1, an upgrade is required to increase the limit).



Enter the serial number (S/N) of the datalogger and click “Check RMS”. If the datalogger has been configured correctly, a screen will open where you can enter the required information relating to the field to be installed.




Once the “location” of the field has been entered, click “Calculate Location Information” to allow the system to obtain the latitude, longitude and time zone of the installation. Click “Confirm” to complete the configuration of the field. You only need to wait a few minutes to view the data flow on the ZCS Azzurro portal.

CAUTION: The location data is essential for the correct operation of the datalogger in the ZCS system. It is important to define it very carefully.


8.4.8.2. Network configuration

At the time of purchase, the Datalogger is configured in DHCP, i.e. dynamic configuration. However, if you want to set up a static configuration for your Datalogger, you can access the internet page via the link RMSxxxxxxx:8888, as shown in the figure (e.g. RMS00000007).



By entering the credentials: username = admin and password = admin, you can change the configuration from dynamic to static by selecting the network window (see [blue arrow](#)) and then the “STATIC” option (see [green arrow](#)).





To complete the operation, click “Apply” (see **red arrow**).

8.4.9. Local monitoring

The datalogger makes it possible to obtain an additional monitoring system (**local monitoring**), which can be used locally on a web page (therefore, also without an internet connection) and accessed from any device present in the same local network as the datalogger.

8.4.9.1. Requirements for installation of local monitoring

In order to install the local monitoring system on the datalogger, the customer must ensure that:

- The datalogger is connected to the local network and to the internet (the internet connection is only required during the installation and configuration of the local monitoring system).
- A static address (to be provided by the customer) with gateway and subnet mask is available for viewing the page locally.

8.4.9.2. Features of local monitoring

After installation and configuration, local monitoring makes it possible to monitor the fundamental parameters of the photovoltaic system, even without an internet connection, from any device connected to the same local network.

In particular, it is possible to monitor the power and energy of the inverters and the storage systems over the last 7 days. It is also possible to view alarms, and other information such as temperature, peak daily power, CO₂ gains and savings.

Below is an example of a local monitoring page.



Figure 280: Example of local monitoring page



9. Warranty terms and conditions

To view the Warranty Terms and Conditions offered by ZCS Azzurro, please refer to the documentation inside the product box and on the website www.zcsazzurro.com.





THE INVERTER THAT LOOKS AT THE FUTURE

zcsazzurro.com



Zucchetti Centro Sistemi S.p.A.
Green Innovation Division
Palazzo dell'Innovazione - Via Lungarno, 167
52028 Terranuova Bracciolini - Arezzo, Italy
zcscompany.com

